	<b>MM30</b>	Doc. N° MO-0035-ING
		Rev. <b>1</b> Pag. <b>1</b> of <b>22</b>

# MICROPROCESSOR MOTOR PROTECTION RELAY TYPE MM30


## OPERATION MANUAL

**SPECIAL EXECUTION  
MM30LT  
VERSION 2.00**



Copyright 1996 Microelettrica Scientifica

1	Mod.431	30-07-97	P.Brasca	D.Abad	
0	EMISSION	01-07-96	P.Brasca	D.Abad	
<b>REV.</b>	<b>DESCRIPTION</b>	<b>DATE</b>	<b>PREP.</b>	<b>CONTR.</b>	<b>APPR.</b>



MICROELETRICA SCIENTIFICA  
MILANO ITALY


## MM30

Doc. N° MO-0035-ING

Rev. 1  
Pag. 2 of 22

### INDEX

<b>1 General utilization and commissioning directions.....</b>	<b>3</b>
1.1 Storage and transportation.....	3
1.2 Installation.....	3
1.3 Electrical connection.....	3
1.4 Measuring inputs and power supply.....	3
1.5 Outputs loading.....	3
1.6 Protection earthing.....	3
1.7 Setting and calibration.....	3
1.8 Safety protection.....	3
1.9 Handling.....	3
1.10 Maintenance.....	4
1.11 Fault detection and repair.....	4
<b>2 General characteristics and operation.....</b>	<b>4</b>
2.1 Power supply.....	4
<b>3 Controls and measurements.....</b>	<b>5</b>
<b>4 Signalization.....</b>	<b>6</b>
<b>5 Output relays.....</b>	<b>6</b>
<b>6 Serial communication.....</b>	<b>7</b>
<b>7 Digital inputs.....</b>	<b>7</b>
<b>8 Test.....</b>	<b>8</b>
<b>9 Keyboard and display operation.....</b>	<b>9</b>
<b>10 Reading of measurements and recorded parameters.....</b>	<b>9</b>
ACT. MEAS (Actual measure).....	9
MAX VAL (Max val).....	10
LASTTRIP (Last trip).....	10
TRIP NUM (Trip number).....	10
<b>11 Reading of programmed settings and relay's configuration.....</b>	<b>11</b>
<b>12 Programming.....</b>	<b>11</b>
13.1 Programming of functions settings.....	11
13.2 Programming the configuration of output relay.....	13
<b>13 Manual and automatic test operation.....</b>	<b>14</b>
<b>14 Maintenance.....</b>	<b>14</b>
<b>15 Electrical characteristics.....</b>	<b>15</b>
<b>17 Connection diagram.....</b>	<b>16</b>
<b>17 Wiring the serial communication bus.....</b>	<b>16</b>
<b>18 Thermal images curves.....</b>	<b>17</b>
<b>19 Inverse time unbalance protection element.....</b>	<b>18</b>
<b>20 Direction for pcb's draw-out and plug-in.....</b>	<b>19</b>
<b>21 Overall dimensions.....</b>	<b>19</b>
<b>22 Overall dimensions PTC converter.....</b>	<b>20</b>
<b>23 Connection PTC converter.....</b>	<b>20</b>
<b>24 Keyboard operational diagram.....</b>	<b>21</b>
<b>25 Setting's form.....</b>	<b>22</b>

 MICROELETTRICA SCIENTIFICA MILANO ITALY	<b>MM30</b>	Doc. N° MO-0035-ING
		Rev. <b>1</b> Pag. <b>3</b> of <b>22</b>

## 1. GENERAL UTILIZATION AND COMMISSIONING DIRECTIONS

Always make reference to the specific description of the product and to the Manufacturer's instruction.  
Carefully observe the following warnings.

### 1.1 - STORAGE AND TRANSPORTATION,

must comply with the environmental conditions stated on the product's instruction or by the applicable IEC standards.

### 1.2 - INSTALLATION,

must be properly made and in compliance with the operational ambient conditions stated by the Manufacturer.

### 1.3 - ELECTRICAL CONNECTION,

must be made strictly according to the wiring diagram supplied with the Product, to its electrical characteristics and in compliance with the applicable standards particularly with reference to human safety.

### 1.4 - MEASURING INPUTS AND POWER SUPPLY,

carefully check that the value of input quantities and power supply voltage are proper and within the permissible variation limits.

### 1.5 - OUTPUTS LOADING,

must be compatible with their declared performance.

### 1.6 - PROTECTION EARTHING

When earthing is required, carefully check its efficiency.

### 1.7 - SETTING AND CALIBRATION

Carefully check the proper setting of the different functions according to the configuration of the protected system, the safety regulations and the co-ordination with other equipment.


### 1.8 - SAFETY PROTECTION

Carefully check that all safety means are correctly mounted, apply proper seals where required and periodically check their integrity.

### 1.9 - HANDLING

Notwithstanding the highest practicable protection means used in designing M.S. electronic circuits, the electronic components and semiconductor devices mounted on the modules can be seriously damaged by electrostatic voltage discharge which can be experienced when handling the modules.

The damage caused by electrostatic discharge may not be immediately apparent but the design reliability and the long life of the product will have been reduced. The electronic circuits produced by M.S. are completely safe from electrostatic discharge (15 KV IEC 255.22.2) when housed in their case; withdrawing the modules without proper cautions expose them to the risk of damage.

 <p>MICROELETRICA SCIENTIFICA MILANO ITALY</p>	<h1 style="text-align: center;">MM30</h1>	Doc. N° MO-0035-ING
		Rev. <b>1</b> Pag. <b>4</b> of <b>22</b>

- a. Before removing a module, ensure that you are at the same electrostatic potential as the equipment by touching the case.
- b. Handle the module by its front-plate, frame, or edges of the printed circuit board. Avoid touching the electronic components, printed circuit tracks or connectors.
- c. Do not pass the module to any person without first ensuring that you are both at the same electrostatic potential. Shaking hands achieves equipotential.
- d. Place the module on an antistatic surface, or on a conducting surface which is at the same potential as yourself.
- e. Store or transport the module in a conductive bag.

More information on safe working procedures for all electronic equipment can be found in BS5783 and IEC 147-OF.

## 1.10 – MAINTENANCE

Make reference to the instruction manual of the Manufacturer ;  
maintenance must be carried-out by specially trained people and in strict conformity with the safety regulations.

## 1.11 – FAULT DETECTION AND REPAIR

Internal calibrations and components should not be altered or replaced.  
For repair please ask the Manufacturer or its authorised Dealers.

Misapplication of the above warnings and instruction relieves the Manufacturer of any liability.

## 2. GENERAL CHARACTERISTICS

Input currents are supplied to 3 current transformers: - two measuring phase current (the third current is computed as vector sum of the two others) - one measuring the earth fault zero-sequence current.  
Phase current rated input can be 1 or 5A (Selectable by movable bridges an relay card)  
For zero-sequence current taps for 1A and 5A input are provided on relay's terminal board.  
Make electric connection in conformity with the diagram reported on relay's enclosure.  
Check that input currents are same as reported on the diagram and on the test certificate.  
The auxiliary power is supplied by a built-in interchangeable module fully isolated an self protected.

### 2.1 – POWER SUPPLY

The relay can be fitted with two different types of **power supply** module :

- |  |   |  |   |
|--|---|--|---|
| a) - {   | { | b) - {   | { |
| 24V(-20%) / 110V(+15%) a.c.<br>24V(-20%) / 125V(+20%) d.c. |   | 80V(-20%) / 220V(+15%) a.c.<br>90V(-20%) / 250V(+20%) d.c. |   |


Before energising the unit check that supply voltage is within the allowed limits.

## 3. CONTROLS AND MEASUREMENTS

Five key buttons allow for local management of all relay's functions.

A 8-digit high brightness alphanumerical display shows the relevant readings (xxxxxxx)  
(see synoptic table fig.1)


**FIG.1**



Pressing this button progressively selects between Measurements Display, Setting Display, Programming, and Test modes


The SELECT button chooses which category of values within the chosen mode to display

When in Program mode, this button stores the newly selected value. If not in Program mode and the relay has tripped, this button resets the relay and all output contacts. If not tripped, this button restores the default display.



The + and - buttons are used to select the actual measurement or display desired when in Measurements Display or Settings Display modes. When in Program mode, these buttons increase or decrease the value of the displayed setting.

When in Program mode, and when all input currents are zero, pressing this recessed button places the relay into active programming mode, allowing any or all of the relays settings to altered.

 <p>MICROELETTRICA SCIENTIFICA MILANO ITALY</p>	<h1 style="text-align: center;">MM30</h1>	Doc. N° MO-0035-ING
		Rev. <b>1</b> Pag. <b>6</b> of <b>22</b>

## 4. SIGNALIZATIONS

Eight signal leds (normally off) are provided:

- a) Red LED  $\Theta >$  : Flashing when the motor heating T overcomes the set alarm level [Ta].  
Illuminated on overtemperature trip.
- b) Red LED **St N°** : Illuminated on tripping of the element for limitation of the number of startings.
- c) Red LED **I <** : Flashing as soon as motor current drops below the set level [I<]  
Illuminated at the end of trip time delay (3 sec).
- d) Red LED **Is >** : Flashing as soon as motor unbalance overpasses the set level [Is>]  
Illuminated on trip after delay [tIs>].
- e) Yellow LED **ROTOR-STALL** : Flashing (after twice the starting time) when motor current overpasses the set level [ILR];  
Illuminated on trip (1 sec delay).
- f) Red LED **I >>** : Flashing when motor current is above the set level [I>]  
Illuminated on trip after delay [tI>].
- g) Red LED  $\nabla \perp$  : Flashing when earth fault current is above the set level [O>]  
Illuminated on trip after delay [tO>].
- h) Yellow LED **START INHIBIT** : Flashing when motor temp. is above the set restart level [Ts] or after StNo trip during the set waiting time [tBst].  
Illuminated when in PROGRAM MODE or when relay internal fault is detected.

### The reset of the leds takes place as follows:


- Leds a,b,c,d,g : -From flashing to off, automatically when the lit-on cause disappears.  
-From ON to OFF, by "ENTER/RESET" push button only if the tripping cause has disappeared.
- Leds e,f,h : -From ON to OFF, automatically when the lit-on cause disappears.

In case of auxiliary power supply failure the status of the leds is recorded and reproduced when power supply is restored.

## 5. OUTPUT RELAYS

Five output relays are available (R1, R2, R3, R4, R5)

- a) - The relays **R1,R2,R3,R4** are normally deenergized (energized on trip): these output relays are user programmable and any of them can be associated to one of the MM30's functions.  
One relay eventually associated to instantaneous element of the function 51 or 51N(64), after pick-up normally drops-out as soon as the tripping cause is cleared (current below the set trip level).  
If the current remains above the trip level longer than the time delay programmed for the same function, the drop-out of the instantaneous relay is anyhow forced after an adjustable waiting time [tBO]. (Breaker failure protection control)  
The reset after tripping of the relays associated to the time delayed functions takes place automatically as soon as the pick-up cause is cleared.

<div></div> <div>MICROELETTICA SCIENTIFICA MILANO ITALY</div>	MM30	Doc. N° MO-0035-ING
		Rev. 1 Pag. 7 of 22

b) - The relay **R5**, normally energized, is not programmable and is deenergized on:

- internal fault
- power supply failure
- during the programming
- max no. of starting attained
- restart lock-out activated

## 6. SERIAL COMMUNICATION (Optional: see relevant instruction manual)

The relays fitted with the serial communication option can be connected via a cable bus or (with proper adapters) a fiber optic bus for interfacing with a Personal Computer (type IBM or compatible).

Via the communication bus all settings and commands available on relay's keyboard can be operated from the computer and viceversa all information available at relay's level can be received at computer's level.

The transmission standard is RS485 (converter 485/232 available).


Each relay is identified by its programmable address code (NodeAd) and can be called from the P.C. fitted with a WINDOWS (version 3.1 or later) program driven by the application program supplied by Microelettrica Scientifica.

## 7. DIGITAL INPUTS

The relay is fitted with three digital inputs activated when the relevant terminals are shorted by a cold contact :

- **R.T.** (terminals 1-2) Remote trip control.  
The input (1-2) can be programmed (see section 12) to operate as Remote Trip [(1-2) = RT] or to power an adapter for RTD input [(1-2) = RTD]+ according to drawing D47089.  
When programmed for Remote Trip control activation of the input energises the output relay which has been associated to this function when programming the configuration of the output relays (see section 12).
- **S.p.C.** (terminals 1-3) Speed switch control.  
The Speed Control input is connected to N/O contact which closes as soon as the motor is running. If the contact does not close within the set start time (tst) from the moment the motor is energised, the Locked Rotor function is tripped. The relay associated ILR is energised, the recording on Last Trip will show cause S.p.C. and trip N° LR will be increased.  
If the Speed Control function is not used, terminals 1-3 must be permanently shorted



<div></div> <div>MICROELETTICA SCIENTIFICA MILANO ITALY</div>	MM30	Doc. N° MO-0035-ING
		Rev. 1 Pag. 8 of 22

- **RTD** (terminals 1-14) Thermal probe.  
This input is alternative to input R.T. ; it only operates when the input 1-2 is programmed [(1-2) = RTD].  
In this case activation of the input 1-14 (terminals shorted) produces the following operation:

- The relay associated to R.T. is energized
- The yellow led n°5 "ROTOR STALL" is flashing.
- The counter of Trip Number of the function T> is incremented
- LastTrip recording shows : "CAUSE RTD"


N.B. For PTC probes a proper adapter D47089 supplied by Microelettrica Scientifica must be used. This device is energized by terminals 1-2 (RT) and guarantees tripping of the RTD function even in case of short circuit or open circuit on the cables of the PTC.

## 8. TEST

Besides the normal "WATCHDOG" and "POWERFAIL" functions, a comprehensive program of self-test and self-diagnostic provides:

- Diagnostic and functional test, with checking of program routines and memory's content, run every time the aux. power is switched-on: the display shows the type of relay and its version number.
- Dynamic functional test run during normal operation every 15 min. (relay's operation is suspended for less than 10 ms). If any internal fault is detected, the display shows a fault message, the Led "PROG/IRF" illuminates and the relay R5 is deenergized.
- Complete test activated by the keyboard or via the communication bus either with or without tripping of the output relays.



 <p>MICROELETTRICA SCIENTIFICA MILANO ITALY</p>	<h1>MM30</h1>	<p>Doc. N° MO-0035-ING</p> <hr/> <p>Rev. <b>1</b> Pag. <b>9</b> of <b>22</b></p>
--	---------------	--

## 9. KEYBOARD AND DISPLAY OPERATION

All controls can be operated from relay's front or via serial communication bus.

The keyboard includes five hand operable buttons **(MODE)**-**(SELECT)**-**(+)**-**(-)**-**(ENTER/RESET)** plus one indirect operable key **(PROG)** (see synoptic table fig.1):

a) - White key **MODE**: when operated it enters one of the following operation modes indicated on the display:

**MEASURE** = Reading of all the parameters actually measured or recorded in the memory

**SET DISP** = Reading of the settings and of the configuration of the output relays as programmed.

**PROG** = Access to the programming of settings and of configuration of output relays.

**TEST PROG** = Access to the manual test routines.

b) - Green key **SELECT** : when operated it selects one of the menus available in the actual operation **MODE**

c) - Red key **"+" AND "-"** : when operated they allow to scroll the information available in the menu entered by the key **SELECT**

d) - Yellow key **ENTER/RESET** : it allows the validation of the programmed settings - the actuation of manual test - the forcing of the default display indication  
- the reset of signal Leds.

e) - Indirect key **PROG** : enables access to the programming.

## 10. READING OF MEASUREMENTS AND RECORDED PARAMETERS


Enter the **MODE "MEASURES"**, **SELECT** the menus **"ACT.MEAS"**-**"MAX VAL"**-**"LASTTRIP"**-**"TRIP NUM"**, scroll available information by key **"+"** or **"-"** .

**ACT.MEAS** = Actual values as measured during the normal operation.

The values displayed are continuously refreshed.

Display	Description
<b>T/Tnxxx%</b>	Actual temperature rise displayed as % of the motor full load temperature rise (0 - 999%)
<b>IAxxxxxA</b>	True R.M.S. value of the current of phase A displayed as primary Amps. (0 - 99999)
<b>IBxxxxxA</b>	As above, phase B.
<b>ICxxxxxA</b>	As above, phase C.
<b>IoxxxxxA</b>	As above, earth fault current.
<b>Id/mxxx%</b>	Positive sequence component of motor current displayed as % of motor full load current. (0 - 999)%
<b>Is/mxxx%</b>	Negative sequence component of motor current displayed as % of motor full load current. (unbalance degree) (0 - 999)%

*NB: If no key is operated within 60 sec. the display is automatically switched to the default indication*

 MICROELETTRICA SCIENTIFICA MILANO ITALY	<b>MM30</b>	Doc. N° MO-0035-ING  Rev. <b>1</b> Pag. <b>10 of 22</b>
---	-------------	--

**MAX VAL** = Highest values recorded during motor run after the starting time (refreshed at each higher value) plus highest values recorded during the starting time (refreshed at each new starting).


Display	Description
<b>T/Tnxxx%</b>	Highest temperature recorded since the start of the run. (0 - 99,9)%
<b>IAxxxxxA</b>	Current of phase A measured during run after starting time (0-99999)
<b>IBxxxxxA</b>	As above, phase B.
<b>ICxxxxxA</b>	As above, phase C.
<b>IoxxxxxA</b>	As above, zero sequence current.
<b>Id/mxxx%</b>	Positive sequence component of motor current.
<b>Is/mxxx%</b>	Negative sequence component of motor current
<b>SAxxxxxA</b>	Current of phase A during the starting time.
<b>SBxxxxxA</b>	As above, phase B.
<b>SCxxxxxA</b>	As above, phase C.
<b>SOxxxxxA</b>	As above, earth fault current.
<b>Sd/mxxx%</b>	Positive sequence current component during starting time.
<b>Ss/mxxx%</b>	Negative sequence current component during starting time.
<b>ts xxxxs</b>	Measure of the start time.

**LASTTRIP** = Display of the function which caused the last tripping of the relay and values of the parameters at the moment of tripping. The memory buffer is refreshed at each new relay tripping.

Display	Description
<b>Causexxx</b>	Function which caused the last tripping: T>; Is>; I>; O>; I<; LR; StN; ITr.
<b>IAxxxxxA</b>	Current of phase A.
<b>IBxxxxxA</b>	Current of phase B.
<b>ICxxxxxA</b>	Current of phase C.
<b>IoxxxxxA</b>	Earth fault current.
<b>Id/mxxx%</b>	Positive sequence component of current.
<b>Is/mxxx%</b>	Negative sequence component of current.
<b>T/Tnxxx%</b>	Motor heating

**TRIP NUM** = Counters of the number of operations for each of the relay functions.  
The memory is non-volatile and can be cancelled only with a secret procedure.

Display	Description
<b>T&gt; xxxxx</b>	Motor overload.
<b>Is&gt;xxxxx</b>	Current unbalance.
<b>I&gt; xxxxx</b>	Overcurrent.
<b>O&gt;xxxxx</b>	Earth fault.
<b>I&lt; xxxxx</b>	No load running.
<b>LRxxxxx</b>	Locked rotor.
<b>StN&gt;xxxx</b>	No of consecutive startings.
<b>ITrxxxxx</b>	Too long starting.

 MICROELETTRICA SCIENTIFICA MILANO ITALY	<h1>MM30</h1>	Doc. N° MO-0035-ING  Rev. 1 Pag. 11 of 22
---	---------------	--

## 11. READING OF PROGRAMMED SETTINGS AND RELAY'S CONFIGURATION

Enter the mode "SET DISP", select the menu "SETTINGS" or "F→RELAY", scroll information available in the menu by keys "+" or "-".

SETTINGS= values of relay's operation parameters as programmed

F→RELAY= output relay associated to the different functions as programmed.

## 12. PROGRAMMING

The relay is supplied with the standard default programming used for factory test.[ Values here below reported ( ---- ) ].

All parameters can be modified as needed in the mode PROG and displayed in the mode SET DISP


**Programming is enabled only if no input current is detected (main switch open).**

As soon as programming is enabled, the Led PRG/IRF flashes and the reclosing lock-out relay R5 is deenergized. Enter MODE "PROG" and SELECT either "SETTINGS" for programming of parameters or "F→RELAY" for programming of output relays configuration; enable programming by the indirect operation key PROG.

The key SELECT now scrolls the available parameters. By the key (+) , (-) the displayed values can be modified; to speed up parameter's variation press the key SELECT while "+" or "-" are pressed.

Press key "ENTER/RESET" to validate the set values.

### 12.1 - PROGRAMMING OF FUNCTIONS SETTINGS




Mode PROG menu SETTINGS. (Production standard settings here under shown).


Display	Description	Setting Range	Step	Units
<b>NodAd 1</b>	Identification number for connection on serial communication bus	1 - 250	1	-
<b>Fn 50 Hz</b>	Mains frequency	50 - 60	10	Hz
<b>In 500Ap</b>	Rated primary current of the phase C.Ts.	1 - 9999	1	A
<b>On 500Ap</b>	Rated primary current of the C.Ts. or of the tore C.T. detecting earth fault current	1 - 9999	1	A
<b>Im 1.0In</b>	Motor full-load current (p.u. of phase C.Ts. rated current)	0.10 - 1.50	0.01	In
<b>Ist 6Im</b>	Motor start-up current (p.u. of motor full load current)	0.5 - 10	0.1	Im
<b>tst 5s</b>	Motor starting time	1 - 120	1	s
<b>ITr.5Ist</b>	Switch-over current of motor starter (p.u. of motor starting current)	Dis - 0.1 - 1	0.1	Ist

Display	Description	Setting Range	Step	Units
tTr 6s	Max switch-over time from start-up	(0,5 - 50)s	0.1	s
<b>AUTOSET? + ENTER</b>		Automatic setting of all the following parameters computed on the base of the setting of the previous parameters		
tm 34min	Thermal time constant of motor while running tm is computed to allow at least one restarting with the motor at its rated full load temperature	1 - 60	1	min
to/tm 3	Steady/running motor thermal time constant	1 - 10	1	-
Ta/n 90%	Prealarm motor heating level (% of motor full-load temperature rise)	50 - 110	1	%Tn
Ts/n100%	Motor restart heating level	40 - 100	1	%Tn
Ib 1.05 Im	Rated maximum continuous current of the motor	1.00 - 1.30	0.01	Im
StNo 6	Max. No of startings allowed within the time tStNo	Dis - 1 - 60	1	-
tStNo60m	Time into which the StNo is counted	1 - 60	1	m
tBSt 12m	Restart inhibition time after tripping of the function StNo (Rm = restart inhibited until manual RESET is operated)	Rm-1-60	1	min
ILR 2Im	Trip level of Locked Rotor function	Dis- 1 - 5	0.1	Im
Is> .3Im	Trip level of inverse time current unbalance protection element	Dis - 0.1 - 0.8	0.1	Im
tIs> 4s	Trip time delay of inverse time current unbalance protection when Is=Im	1 - 8	1	s
I< .2Im	Trip level of undercurrent (no-load running) element	Dis - 0.15 - 1	0.01	Im
I> 2Ist	Trip level of overcurrent element	Dis - 1 - 5	0.1	Ist
tI> .1s	Trip time delay of overcurrent element	0.05 - 1	0.01	s
O> .1On	Trip level of earth fault element	Dis- 0.02 - 2	0.01	On
tO> .2s	Trip time delay of earth fault element	0.05 - 5	0.01	s
tBO .15s	Reset time delay of the blocking output relay	0.05 - 0.5	0.01	s
(1-2)= RT	Selection of the operation mode of the digital input 1-2: [(1-2)=RT]= operation os Remote Trip function ; [(1-2)=RTD]= operation of the RTD function (see section 7)	RT - RTD	-	-

**The setting Dis indicates that the function is disactivated.**

 MICROELETTRICA SCIENTIFICA MILANO ITALY	<b>MM30</b>	Doc. N° MO-0035-ING  Rev. <b>1</b> Pag. <b>13 of 22</b>
---	-------------	--

## 12.2 - PROGRAMMING THE CONFIGURATION OF OUTPUT RELAYS




Mode PROG menu F→RELAY (Production standard settings here under shown).

The key "+" operates as cursor; it moves through the digits corresponding to the four programmable relays in the sequence 1,2,3,4,(1= relay R1, etc.) and makes start flashing the information actually present in the digit. The information present in the digit can be either the number of the relay (if this was already associated to the function actually on programming) or a dot (-) if the relay was not yet addressed.

The key "-" changes the existing status from the dot to the relay number or viceversa.

After programming of any function (T>, Ta, etc.), press the key ENTER to validate the configuration selected,

Display	Description
T> 1---	Overload tripping operates relay R1,R2,R3,R4.
Ta -2--	Overload prealarm tripping operates relay R1,R2,R3,R4.
ITr ----	Starting switch-over tripping operates relay R1,R2,R3,R4.
StNo ----	Start No limitation tripping operates relay R1,R2,R3,R4.
ILR 1---	Locked Rotor tripping operates relay R1,R2,R3,R4.
tIs> 1---	Time delayed unbalance tripping operates relay R1,R2,R3,R4.
I< ---4	No load running tripping operates relay R1,R2,R3,R4.
I> ----	Instantaneous overcurrent tripping operates relay R1,R2,R3,R4.
tI> 1---	Time delayed overcurrent tripping operates relay R1,R2,R3,R4.
O> ----	Instantaneous earth fault tripping operates relay R1,R2,R3,R4.
tO> 1---	Time delayed earth fault tripping operates relay R1,R2,R3,R4.
RT ----	The function RT or RTD operates relay R1,R2,R3,R4.

	<h1 style="text-align: center;">MM30</h1>	Doc. N° MO-0035-ING
		Rev. <b>1</b> Pag. <b>14 of 22</b>

## 13. MANUAL AND AUTOMATIC TEST OPERATION

### - Mode "TESTPROG" subprogram "**W/O TRIP**":

Operation of the yellow key activates a complete test of the electronics and the process routines.

All the leds are lit-on and the display shows (TEST RUN).

If the test routine is successfully completed the display switches-over to the default reading (T/Tnxxx%)

If an internal fault is detected, the display shows the fault identification code and the relay R5 is deenergized. This test can be carried-out even during the operation of the relay without affecting the relay tripping in case a fault takes place during the test itself.

### - Mode "TESTPROG" subprogram "**WithTRIP**":

Access to this program is enabled only if the current detected is zero (breaker open).

Pressing the yellow key the display shows "TEST RUN?". A second operation of the yellow key starts a complete test which also includes the activation of all the output relays.

The display shows (TEST RUN) with the same procedure as for the test with W/O TRIP.

Every 15 min during the normal operation the relay automatically initiates an auto test procedure (duration  $\leq 10\text{ms}$ ). If any internal fault is detected during the auto test, the relay R5 is deenergized, the relevant led is activated and the fault code is displayed.

### - Further operation of key SELECT instead of the TEST programs gives the indication of the version and production date of the firmware.



## CAUTION

Running the **WithTRIP** test will operate all of the output relays. Care must be taken to ensure that no unexpected or harmful equipment operations will occur as a result of running this test.

It is generally recommended that this test be run only in a bench test environment or after all dangerous output connections are removed.


## 14. MAINTENANCE

No maintenance is required. Periodically a functional check-out can be made with the test procedures described under MANUAL TEST chapter. In case of malfunctioning please contact Microelettrica Scientifica Service or the local Authorised Dealer mentioning the relay's Serial No reported in the label on relays enclosure.

## WARNING

In case of Internal Relay Fault detection, proceed as here-below indicated :

- If the error message displayed is one of the following “DSP Err”, “ALU Err” ,”KBD Err” ,”ADC Err”, switch off power supply and switch-on again. If the message does not disappear send the relay to Microelettrica Scientifica (or its local dealer) for repair.
- If the error message displayed is “E2P Err” , send the relay to Microelettrica Scientifica (or its local dealer) for repair.


<div></div> <div>MICROELETTRICA SCIENTIFICA MILANO ITALY</div>	<div>MM30</div>	Doc. N° MO-0035-ING
		Rev. 1 Pag. 15 of 22

## 15. ELECTRICAL CHARACTERISTICS

- Reference standards	IEC 255, IEC1000; IEEE C37; CE Directive	
- Dielectric test voltage	IEC 255-5	: 2kV, 1 min.
- Impulse test voltage	IEC 255-5	: 5kV (c.m.), 2 kV (d.m.) - 1,2/50µs
- HF disturbance test with damped oscillatory wave (1MHz burst test)	IEC255-22-1 class 3	: 2,5kV (m.c.), 1kV (d.m.)
- Electrostatic discharge test	IEC1000-4-2 level 4	: 15 kV
- Conducted disturbances immunity test	IEC1000-4-6 level 3	: 0.15-80MHz, 10V/m
- Radiated electromagnetic field immunity test	IEC1000-4-3 level 3	: 80-1000MHz, 10V/m
- Electrical fast transient/burst	IEC1000-4-4 level 4	: 4kV, 2.5kHz, 15/300ms (c.m.) 2kV, 5kHz, 15/300ms (d.m.)
- Surge immunity test	IEC1000-4-5 level 4	: 4kV(c.m.), 2kV(d.m.)
- Oscillatory waves (Ring waves)	IEC1000-4-12 level 4	: 4kV(c.m.), 2kV(d.m.)
- Power frequency magnetic test	IEC1000-4-8	: 1000A/m
- Pulse magnetic field	IEC1000-4-9	: 1000A/m, 8/20µs
- Damped oscillatory magnetic field	IEC1000-4-10	: 1000A/m, 0.1-1MHz
- Immunity test for voltage dips, short interruptions and voltage variations	IEC1000-4-11	
- HF inducted voltage	IEC1000-4-1 A.2.6 level 4	: 100V, 0.01-1MHz
CE EMC Compatibility:		
- Electromagnetic emission	EN50081-2	
- Radiated electromagnetic disturbance test	EN50082-2	
- Resistance to vibration and shocks	IEC255-21-1, IEC255-21-2	
- Accuracy at reference value of influencing factors	1% In; 0,1% On	for measure +/- 10ms for times
- Rated input current	In = 1 or 5A, On = 1 or 5A	
- Current overload	200A for 1 sec; 10A continuos	
- Burden on current inputs	Phase : 0.01VA at In = 1A; 0.2VA at In = 5A Neutral : 0.03VA at 1A ; 0.2VA at 5A	
- Average power supply consumption	8,5 VA	
- Output relays	rating 5 A; Vn = 380 V A.C. resistive switching = 1100W (380V max) make = 30 A (peak) 0,5 sec. break = 0.3 A, 110 Vcc, L/R = 40 ms (100.000 op.)	
- Operation ambient temperature	-20°C / +60°C	
- Storage temperature	-30°C / +80°C	

**Microelettrica Scientifica S.p.A.** - 20089 Rozzano (MI) - Italy - Via Alberelle, 56/68  
Tel. ((#39) 2 575731 - Fax ((#39) 2 57510940 - Telex 351265 MIELIT I

*The performances and the characteristics reported in this manual are not binding and can modified at any moment without notice*




MICROELETTRICA SCIENTIFICA  
MILANO ITALY

**MM30**

Doc. N° MO-0035-ING


Rev. **1**  
Pag. **16 of 22**

## 16. CONNECTION DIAGRAM (SCE1269 Rev.5)




## 17. WIRING THE SERIAL COMMUNICATION BUS (SCE1309 Rev.0)


### CONNECTION TO RS485



### FIBER OPTIC CONNECTION








MICROELETRICA SCIENTIFICA  
MILANO ITALY


**MM30**

Doc. N° MO-0035-ING

Rev. **1**  
Pag. **17 of 22**

## 18. THERMAL IMAGE CURVES (TU0249 Rev.1)






MICROELETTRICA SCIENTIFICA  
MILANO ITALY


MM30

Doc. N° MO-0035-ING

Rev. 1  
Pag. 18 of 22

## 19. INVERSE TIME UNBALANCE PROTECTION ELEMENT (TU0248 Rev.0)



 <p>MICROELETTRICA SCIENTIFICA MILANO ITALY</p>	<h1>MM30</h1>	<p>Doc. N° MO-0035-ING</p> <hr/> <p>Rev. <b>1</b> Pag. <b>19 of 22</b></p>
--	---------------	--


## 20. DIRECTION FOR PCB'S DRAW-OUT AND PLUG-IN

### DRAW-OUT


Rotate clockwise the screws ① and ② in the horizontal position of the screws-driver mark.  
Draw-out the PCB by pulling on the handle ③


### PLUG-IN

Rotate clockwise the screws ① and ② in the horizontal position of the screws-driver mark.  
Slide-in the card on the rails provided inside the enclosure.  
Plug-in the card completely and by pressing the handle to the closed position.  
Rotate anticlockwise the screws ① and ② with the mark in the vertical position (locked).



## 21. OVERALL DIMENSIONS






MICROELETTRICA SCIENTIFICA  
MILANO ITALY

**MM30**


Doc. N° MO-0035-ING


Rev. **1**  
Pag. **20 of 22**

## 22. OVERALL DIMENSIONS PTC CONVERTER (D47089 Rev.0)




## 23. CONNECTIONS PTC CONVERTER (D47089 Rev.0)



 <p>MICROELETRICA SCIENTIFICA MILANO ITALY</p>	<p><b>MM30</b></p>	<p>Doc. N° MO-0035-ING</p>
		<p>Rev. <b>1</b> Pag. <b>21</b> of <b>22</b></p>

## 24. KEYBOARD OPERATIONAL DIAGRAM (D46116 Rev.1)



MICROELETTRICA SCIENTIFICA  
MILANO ITALY

## MM30

Doc. N° MO-0035-ING

Rev. 1  
Pag. 22 of 22

### 25. SETTING'S FORM

Date :					Number Relay:				
RELAY PROGRAMMING									
Default Setting					Actual Setting				
Variable	Value	Measurement Unit			Variable	Value	Measurement Unit		
NodAd	1	-----			NodAd		-----		
Fn	50	Hz			Fn		Hz		
In	500	Ap			In		Ap		
On	500	Ap			On		Ap		
Im	1.0	In			Im		In		
Ist	6	Im			Ist		Im		
tst	5	s			tst		s		
ITr	.5	Ist			ITr		Ist		
tTr	6	s			tTr		s		
AUTOSET? + ENTER					AUTOSET? + ENTER				
tm	34	min			tm		min		
to/tm	3	-----			to/tm		-----		
Ta/n	90	%			Ta/n		%		
Ts/n	100	%			Ts/n		%		
Ib	1.05	Im			Ib		Im		
StNo	6	-----			StNo		-----		
tStNo	60	m			tStNo		m		
tBSt	12	m			tBSt		m		
ILR	2	Im			ILR		Im		
Is>	.3	Im			Is>		Im		
tIs>	4	s			tIs>		s		
I<	.2	Im			I<		Im		
I>	2	Ist			I>		Ist		
tI>	.1	s			tI>		s		
O>	.1	On			O>		On		
tO>	.2	s			tO>		s		
tBO	.15	s			tBO		s		
CONFIGURATION OF OUTPUT RELAYS									
Default Setting					Actual Setting				
Protective Elem.	Output Relays				Protective Elem.	Output Relays			
T>	1	-	-	-	T>				
Ta	-	2	-	-	Ta				
ITr	-	-	-	-	ITr				
StNo	-	-	-	-	StNo				
ILR	1	-	-	-	ILR				
tIs>	1	-	-	-	tIs>				
I<	-	-	-	4	I<				
I>	-	-	-	-	I>				
tI>	1	-	-	-	tI>				
O>	-	-	-	-	O>				
tO>	1	-	-	-	tO>				
RT	-	-	-	-	RT				