

MICROPROCESSOR  
MOTOR PROTECTION  
RELAY

TYPE

**“MC2-30M”**

OPERATION MANUAL





1. General Utilization and Commissioning Directions	4
1.1 - Storage and Transportation	4
1.2 - Installation	4
1.3 - Electrical Connection	4
1.4 - Measuring Inputs and Power Supply	4
1.5 - Outputs Loading	4
1.6 - Protection Earthing	4
1.7 - Setting and Calibration	4
1.8 - Safety Protection	4
1.9 - Handling	4
1.10 - Maintenance	4
1.11 - Waste Disposal of Electrical & Electronic Equipment	4
1.12 - Fault Detection and Repair	4
2. General	5
2.1 - Power Supply	5
3. Front Panel	5
4. Keyboard and Display	6
4.1 - Display	6
5. Icons of Display	7
6. Signalization	8
6.1 - Leds Manual Reset	8
6.2 - Display of the last trip	8
7. Leds Configuration	9
7.1 - Name	10
7.2 - Link enable	10
7.3 - Status	10
7.4 - Light Prog.	10
7.5 - Funct. Mode	10
7.6 - Functions	10
7.7 - Table 1	11
7.8 - Example: Change settings for "Led1"	12
7.8.1 - "Link Enable"	12
7.8.2 - "Flashing"	12
7.8.3 - "Funct.Mode"	13
7.8.4 - "Functions"	13
8. User Variables	14
8.1 - Name	14
8.2 - User Descr.	14
8.3 - Linked functions	14
8.4 - OpLogic	14
8.5 - Timer	14
8.6 - Timer type	14
8.7 - Extra	14
8.8 - Logical status	14
8.9 - Example: Setting "User Variable"	14
8.9.1 - "User description" (User descr.)	15
8.9.2 - "Linked Functions"	15
8.9.3 - "Operation Logic" (Oplogic)	16
8.9.4 - "Timer"	16
8.9.5 - "Timer type"	17
8.9.6 - "Extra"	17
9. Local Commands	18
10. Measure	19
11. Maximum Values	20
12. Trip Recording	21
13. Partial Counters	23
14. Total Counters	24
15. Events	25
15.1 - Events on display	26
16. System (System parameters)	27
17. Settings	28
17.1 - Modifying the setting of variables	29
17.2 - Password	30
17.3 - Menu: <b>Communic.</b> (Communication)	31
17.3.1 - Description of variables	31
17.3.2 - Front Panel USB serial communication port (RS232)	31
17.3.3 - Cable for connection from Relay to Personal Computer	31
17.3.4 - Main serial communication port (RS485)	31
17.4 - Menu: <b>Customize</b> (Human Machine Interface)	32
17.4.1 - Description of variables	32
17.5 - Function: <b>FileSys</b> (File system and Disk management)	33
17.5.1 - Description of variables	33
17.5.2 - Download file informations	33
17.6 - Function: <b>T&gt;</b> (Thermal Image F49)	34



17.6.1 - Description of variables	34
17.6.2 - Trip and Alarm	34
17.7 - Function: <b>1I&gt;</b> (First Overcurrent Element F50/51)	36
17.7.1 - Description of variables	36
17.7.2 - Blocking Logic (BO-BI)	37
17.7.3 - Automatic doubling of Overcurrent thresholds on current inrush	37
17.8 - Function: <b>2I&gt;</b> (Second Overcurrent Element F50/51)	38
17.8.1 - Description of variables	38
17.9 - Function: <b>3I&gt;</b> (Third Overcurrent Element F50/51)	38
17.9.1 - Description of variables	38
17.10 - Function: <b>1Io&gt;</b> (First Earth Fault Element 50N/51N)	39
17.10.1 - Description of variables	39
17.11 - Function: <b>2Io&gt;</b> (Second Earth Fault Element 50N/51N)	39
17.11.1 - Description of variables	39
17.12 - Function: <b>3Io&gt;</b> (Third Earth Fault Element 50N/51N)	40
17.12.1 - Description of variables	40
17.13 - Function: <b>1Is&gt;</b> (First Negative Sequence Element F46)	41
17.13.1 - Description of variables	41
17.13.2 - Time/Current operation of the first Current Unbalance element "f(t)"	41
17.14 - Function: <b>2Is&gt;</b> (Second Negative Sequence Element F46)	41
17.14.1 - Description of variables	41
17.15 - Function: <b>MotSt</b> (Motor Start)	42
17.15.1 - Description of variables	42
17.16 - Function: <b>LR</b> (Locked Rotor - Rotor jam)	42
17.16.1 - Description of variables	42
17.17 - Function: <b>StNo</b> (Limitation Start Number)	42
17.17.1 - Description of variables	42
17.18 - Function: <b>StSeq</b> (starting Sequence Control)	43
17.18.1 - Description of variables	43
17.18.2 - Operation	43
17.19 - Function: <b>I&lt;</b> (No load running)	43
17.19.1 - Description of variables	43
17.19.2 - Operation	43
17.20 - Function: <b>TCS</b> (Trip Circuit Supervision)	44
17.20.1 - Description of variables	44
17.20.2 - Operation	44
17.21 - Function: <b>IRF</b> (Internal Relay Fault)	45
17.21.1 - Description of variables	45
17.21.2 - Operation	45
17.22 - Function: <b>BrkFail</b> (Breaker Failure)	45
17.22.1 - Description of variables	45
17.22.2 - Operation	45
17.23 - Function: <b>Oscillo</b> (Oscillographic Recording)	46
17.23.1 - Description of variables	46
17.23.2 - Operation	46
17.23.3 - Available on software	47
17.23.4 - Setting "User Trigger Oscillo"	48
17.23.5 - Example: Setting "Oscillo Trigger Logic"	49
17.24 - Function: <b>CB Mngn</b> (Control C/B)	52
17.24.1 - Description of variables	52
17.24.2 - Push-Buttons (Programmable only via software)	52
17.25 - Function: <b>ExtResCfg</b> (External Reset Configuration)	54
17.25.1 - Description of variables	54
18. Input - Output (via software)	54
18.1 - Digital Input	54
18.2 - "DI" Configuration (via software)	54
18.2.1 - Example	55
18.3 - Physical Outputs	56
18.4 - "DO" Configuration	56
18.4.1 - Example configuration	56
18.4.2 - Functions - Operation Mode	57
19. InfoStatus	59
20. Date and Time	60
20.1- Clock synchronization	61
21. Healthy (Diagnostic Information)	62
22. Dev.Info (Relay Version)	62
23. Maintenance	62
24. Wiring Diagram	63
25. Overall Dimensions	63
26. Electrical Characteristics	64



## 1. General Utilization and Commissioning Directions

---

Always make reference to the specific description of the product and to the Manufacturer's instruction. Carefully observe the following warnings.

### *1.1 - Storage and Transportation*

---

Must comply with the environmental conditions stated in the product's specification or by the applicable IEC standards.

### *1.2 - Installation*

---

Must be properly made and in compliance with the operational ambient conditions stated by the Manufacturer.

### *1.3 - Electrical Connection*

---

Must be made strictly according to the wiring diagram supplied with the Product, to its electrical characteristics and in compliance with the applicable standards particularly with reference to human safety.

### *1.4 - Measuring Inputs and Power Supply*

---

Carefully check that the value of input quantities and power supply voltage are proper and within the permissible variation limits.

### *1.5 - Outputs Loading*

---

Must be compatible with their declared performance.

### *1.6 - Protection Earthing*

---

When earthing is required, carefully check its effectiveness.

### *1.7 - Setting and Calibration*

---

Carefully check the proper setting of the different functions according to the configuration of the protected system, the safety regulations and the co-ordination with other equipment.

### *1.8 - Safety Protection*

---

Carefully check that all safety means are correctly mounted, apply proper seals where required and periodically check their integrity.

### *1.9 - Handling*

---

Notwithstanding the highest practicable protection means used in designing electronic circuits, the electronic components and semiconductor devices mounted on the modules can be seriously damaged by electrostatic voltage discharge which can be experienced when handling the modules.

The damage caused by electrostatic discharge may not be immediately apparent, but the design reliability and the long life of the product will have been reduced. The electronic circuits are completely safe from electrostatic discharge (8 KV IEC 255.22.2) when housed in their case; withdrawing the modules without proper cautions expose them to the risk of damage.

### *1.10 - Maintenance*

---

Make reference to the instruction manual of the Manufacturer; maintenance must be carried-out by specially trained people and in strict conformity with the safety regulations.

### *1.11 - Waste Disposal of Electrical & Electronic Equipment*

---

(Applicable throughout the European Union and other European countries with separate collection program). This product should not be treated as household waste when you wish dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequence to the environment and human health, which could otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resource.

### *1.12 - Fault Detection and Repair*

---

Internal calibrations and components should not be altered or replaced. For repair please ask the Manufacturer or its authorized Dealers.

Misapplication of the above warnings and instruction relieves the Manufacturer of any liability.

**2. General**

The main features of the relays are:

User friendly front face with hi-resolution graphic display (240x128), 10 programmable signal Leds, 6 push-buttons (configurable) and four push-button for complete local management, USB for local communication.

Eight user programmable Output Relays.

Eight opto-isolated, self powered Digital Inputs.

Additional RS485 communication port

Input currents are supplied to 3 current transformers: measuring phase currents.

An additional internal CT directly measures the residual (Zero Sequence) current of the three inputs.

Current inputs can be 1 or 5A: selection between 1A or 5A is made by movable jumpers provided inside the Relay.


**2.1 - Power Supply**

The relay can be fitted with two different types of **power supply**:

Type 1	24V(-20%) / 110V(+15%) a.c.	24V(-20%) / 125V(+20%) d.c.
Type 2	80V(-20%) / 220V(+15%) a.c.	90V(-20%) / 250V(+20%) d.c.

Before energizing the unit check that supply voltage is within the allowed limits.

**3. Front Panel**



## 4. Keyboard and Display

**1**

↓

**6**

**↑**

**↙ ↘**

**↖ ↗**

**Pushbuttons** Programmable


**Navigation menu** By these buttons the options showed in correspondence on the display are selected.

**Increase** These buttons are used to scroll the items of the different menus (Local Control, Measurements, Energy metering etc).

**Decrease**

### 4.1 - Display

The 240x128 pixel hi-resolution LCD display the available information (menu, etc.).





## 5. Icons of Display


	<i>LocalCmd</i>	Local Commands
	<i>Measure</i>	Actual Measurements
	<i>MaxVal</i>	Maximum Values
	<i>TripRec.</i>	Trip Recording
	<i>Counter</i>	Partial Counters (Resettable Counter)
	<i>ROCnt</i>	Total Counter (Read Only Counter)
	<i>Events</i>	Event Recording
	<i>Setting</i>	Function Settings
	<i>System</i>	System Settings
	<i>InfoStatus</i>	Information Status
	<i>TimeDate</i>	Time And Date
	<i>Healthy</i>	Diagnostic Information
	<i>Dev.Info</i>	Relay Version

**6. Signalization**

Eleven signal leds are provided:

1	Led Power Supply	Not programmable	Green
10	Leds	Programmable (via software)	

N°	Colours
1	Green
2	Green
3	Green
4	Yellow
5	Red
6	Red
7	Red
8	Yellow
9	Red
10	Green



**6.1 - Leds Manual Reset**

For Leds manual reset operate as follows:

- Press "**Menu**" for access to the main menu with icons.
- Select icon "**LocalCmd**".
  - Press "**Select**",
- Select "**LedClear**".
  - Press "**Select**" to execute the command.
- When command has been executed the display shows "**Command Done**";


**6.2 - Display of the last trip**

Beside the signalization of the led "Trip", indicating a generic function trip, the display shows a window indicating the latest function that was tripped and the number of events that are stored in the memory. The display will show this window until the reset button or external reset are operated.

- Press "**Menu**" to access to the main menu with icons. Press "**Home**" to erase trip visualization. Ex. "tTCS" (flashing) is the last trip.


## 7. Leds Configuration (only via software)

The relay manage up to 10 signal leds (Programmable), 1 led "Power" (green).




For Leds programming (only via software) operate as follows:

- Open the software program and connect to the relay.
- Select "Change Windows" from "Menu" button (options)



- Select "Led Setting"



The window for leds configuration will show:

ID	Name	Link enable	Status	Light prog.	Funct. Mode	Functions
1	Led 1	Not linked	Light off	Light on	Volatile	BF
2	Led 2	Not linked	Light off	Light on	Volatile	BF

**7.1 - Name**

Led name – for leds position see picture

**7.2 - Link enable**

<i>Linked</i>	=	Enable to operate
<i>Not Linked</i>	=	Disable

**7.3 - Status**

<i>Light-off</i>	=	Normal condition
<i>Light-on</i>	=	When cause appear led is illuminated
<i>Flashing</i>	=	When cause appear led is flashing

See "Light Prog"

**7.4 - Light Prog.**

<i>Light-on</i>	=	When cause appear led is illuminated
<i>Flashing</i>	=	When cause appear led is flashing

**7.5 - Funct. Mode**

<i>Volatile</i>	=	When cause disappear led turn-off (Not memorized)
<i>Latched</i>	=	When cause disappear led remain illuminated (memorized)

**7.6 - Functions**

Select the function assigned to specific led (see table 1).  
 It's possible to configure only one function for each led.  
 For configuration multiple functions use "UserVar" function.



7.7 - Table 1

Tal	Alarm	Thermal Image T>
T>	Trip	
1I>	Start	First overcurrent element
t1I>	Trip	
2I>	Start	Second overcurrent element
t2I>	Trip	
3I>	Start	Third overcurrent element
t3I>	Trip	
1Io>	Start	First earth fault element
t1Io>	Trip	
2Io>	Start	Second earth fault element
t2Io>	Trip	
3Io>	Start	Third earth fault element
t3Io>	Trip	
1Is>	Start	First negative sequence current element
t1Is>	Trip	
2Is>	Start	Second negative sequence current element
t2Is>	Trip	
I<	Start	No Load Running element
tI<	Trip	
ILR	Start	Locked Rotor element
tILR	Trip	
IRF	Start	Internal Relay Failure
tIRF	Trip	
BF		BF (Breaker Failure)
tTCS		Trip coil supervision
MotOn		Motor On
LimStNum		Limitation Startings Number
StSeqSucc		Start Sequence
Itr		Switch-over current
DskClean		Disk near Full clean operation is required
DskFull		Disk Full Write should be lock
DskWR		Disk write in progress
DskFRMT		Disk Format in progress
DskCHK		Check disk in progress
rDskAttach	Not used	Removable disk usb attach
rDskDetach		Removable disk usb detach
rDskDtchable		Removable disk usb now detachable
rDskClean		Removable disk usb near to full clean operation is required
rDskFull		Removable disk usb full, write locked
rDskWR		Removable disk usb write in progress
rDskFRMT		Removable disk usb format in progress
rDskCHK		Removable disk usb check in progress
manOpCmd		Manual Open Command
L/Rdisc		Local/Remote signal Discrepancy
CL-Cmd	Close Command	
C/Bfail	Circuit Breaker failure	
UserTriggerOscillo	User Variable for Oscillographic Recording	
UserVar<0>		
to		User Variable
UserVar<24>		
Vcc		"One" logic
Gnd		"Zero" logic
Reset		Reset signal logic
P1		Push-button 1
P2		Push-button 2
P3		Push-button 3
P4		Push-button 4
P5		Push-button 5
P6		Push-button 6
Gen.Start	Start	Generic
Gen.Trip	Trip	
0.D1		Digital Inputs
0.D1Not		
to		
0.D8		
0.D8Not		
0.R1		Output relays
to		
0.R8		

*7.8 - Example: Change settings for "Led1"*


Change settings for "**Led1**" : "Enable", "Flashing", "Latched", "1I>".

Main Windows:


ID	Name	Link enable	Status	Light prog.	Funct. Mode	Functions
1	Led 1	Not linked	Light off	Light on	Volatile	BF
2	Led 2	Not linked	Light off	Light on	Volatile	BF
3	Led 3	Not linked	Light off	Light on	Volatile	BF
4	Led 4	Not linked	Light off	Light on	Volatile	BF
5	Led 5	Not linked	Light off	Light on	Volatile	BF
6	Led 6	Not linked	Light off	Light on	Volatile	BF
7	Led 7	Not linked	Light off	Light on	Volatile	BF
8	Led 8	Not linked	Light off	Light on	Volatile	BF
9	Led 9	Not linked	Light off	Light on	Volatile	BF
10	Led 10	Not linked	Light off	Light on	Volatile	BF

*7.8.1 - "Link Enable"*

Select "**Link enable**" related to "Led 1" and press right button on mouse, select "Value change":




Select "**Linked**" and press "OK" (if Password is request, see § Password):




*7.8.2 - "Flashing"*

Select "**Light prog**" related to Led 1 and press right button on mouse, select "Value change":




Select "**Flashing**" and press "OK" (if Password is request, see § Password):




7.8.3 - "Funct.Mode"

Select "**Funct.Mode**" related to Led 1 and press right button on mouse, select "Value change":




Select "**Latched**" and press "OK"  
(if Password is request, see § Password):




7.8.4 -"Functions"

Select "**Functions**" related to Led 1 and press right button on mouse, select "Value change":



Select "**1I>**" and press "OK"  
(if Password is request, see § Password):



**8. User Variables**

The "User Variable" is a result of a logical operation (Or, AND, ecc...), it can be used like other logical output. This operation is possible only via software.

Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
------	-------------	------------------	---------	-------	------------	-------	----------------

**8.1 - Name**

Internal progressive name

**8.2 - User Descr.**

Custom identification label for user variable

**8.3 - Linked functions**

Selection functions

**8.4 - OpLogic**

Operation Logic = [None, OR, AND, XOR, NOR, NAND, NOT, Ff-SR, Counter, Rise-UP, Fall-Down]

**8.5 - Timer**

Time delay (0-600)s, step 0.01s

**8.6 - Timer type**

<i>Delay</i>	=	Add a delay on output activation. The "Timer" is edge triggered on rise edge.
<i>Monostable P</i>	=	Activated the output for the time "Timer"
<i>Monostable N</i>	=	Disactivated the output for the time "Timer".
<i>Blinking</i>	=	The output switches periodically at the frequency defined by "Timer".
<i>Delay-Fall-Down</i>	=	<i>Delay-Fall-Down</i>

**8.7 - Extra**

Extra Time (0 - 65000)s, step 1s


**8.8 - Logical status**

"User Variable" Logical status


**8.9 - Example: Setting "User Variable"**

Open software program and connect to the relay.

Select "Change Windows" from "Menu" button



Select "User Variable"




Setting for "UserVar<0>" : "Current Trip", "1I>,2I>,3I>", "OR", "1", "Monostable P", "10".


ID	Name	User descr.	Linked functio	OpLogic	Timer	Timer type	Extra	Logical status
1	UserTrigger Oscillo	UserTrigger Oscillo		None	0	Delay	0	0
2	UserVar <0>	Current Trip...	1I>,2I>,3I>	OR	1	Monostable P	10	0

8.9.1 - "User description" (User descr.)

Select "**User descr**" related to "UserVar<0>" and press right button on mouse, select "Value change":




Insert "**Current Trip**" into box and press "OK":





8.9.2 - "Linked Functions"

Select "**Linked Functions**" related to "UserVar<0>" and press right button on mouse, select "Value change":




Select "**1I>, 2I>, 3I>**" from "Available" box via push-button "<Add", and press "OK".  
For remove functions, use push-button ">Remove".




8.9.3 - "Operation Logic" (Oplogic)

Select "**Oper Logic**" related to "UserVar<0>" and press right button on mouse, select "Value change":




Insert "**OR**" into box and press "OK":




8.9.4 - "Timer"

Select "**Timer**" related to "UserVar<0>" and press right button on mouse, select "Value change":




Select "**1**" into box and press "OK":




8.9.5 - "Timer type"

Select "**Timer**" related to "UserVar<0>" and press right button on mouse, select "Value change":




Select "**Monostable P**" into box and press "OK":




8.9.6 - "Extra"

Select "**Extra**" related to "UserVar<0>" and press right button on mouse,



Select "**10**" into box and press "OK":







9. Local Commands

“**Local Commands**” allow to operate from relay front face controls like Thermal Memory reset, Leds reset, etc.

Menu		Description	Password
Led	Clear	Reset of signal Leds	No
Relays	Clear	Manual reset of output relays	No
main C/B	Cl.	Manual C/B closing (conditioned by Password)	Yes
main C/B	Op.	Manual C/B opening (conditioned by Password)	Yes
Event	Clear	Reset Events	Yes
LTrip	Clear	Reset Last Trip	Yes
Counter	Clear	Reset Counters	Yes
HistFail	Clear	Reset of Internal Failure Historic records	Yes
Reset	StNo	Reset of the Starts Number	Yes
Reset	Term	Reset to zero of the accumulations relevant to Thermal Image and Interruption Energy (only if T> is enable)	Yes
Leds	Test	Signal Leds test	No
Force	Osc	Force Oscillo Recording	Yes
Format	iDisk	Format internal disk	Yes
Check	iDisk	Check internal disk	Yes


To operate one command by the Front Face Keyboard, proceed as follows (Led Clear in the present example).


- 
  - Press “**Menu**” for access to the main menu with icons.
- 
  - Select “**LocalCmd**” icon with pushbutton “**Increase**” or “**Decrease**”.
  - Press “**Select**” for access.
- 
  - Select with pushbutton “**Increase**” or “**Decrease**” the menu “**LedClear**”.
  - Press “**Select**” to execute the command. (if Password is request, see § Password).
- 
  - When command has been executed the display shows “**Command Done**”; go to “3”.


## 10. Measure

Real time values as measured during the normal operation.

- 1**


  - Press "**Menu**" for access to the main menu with icons.
  
- 2**


  - Select "**Measure**" icon with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  
- 3**


  - Scroll the menu "**Measure**" with pushbutton "**Increase**" or "**Decrease**" to display the measurement.
  - Press "**Exit**" to go to the main menu.

<b>Imx</b>	(0 ÷ 99999)	A	Largest of the 3 phase-currents (Ia,Ib,Ic)
<b>Ia</b>	(0 ÷ 99999)	A	RMS value phase A current
<b>Ib</b>	(0 ÷ 99999)	A	RMS value phase B current
<b>Ic</b>	(0 ÷ 99999)	A	RMS value phase C current
<b>Io</b>	(0 ÷ 99999)	A	RMS value of Zero Sequence Current
<b>I1</b>	(0 ÷ 99999)	In	Positive sequence current
<b>I2</b>	(0 ÷ 99999)	In	Negative Sequence current
<b>Tem</b>	(0 ÷ 99999)	%T	Thermal status as % of the full load continuous operation temperature Tn
<b>tst</b>	(0 ÷ 99999)	s	Motor starting time
<b>Ist</b>	(0 ÷ 99999)	A	Max current during motor starting

## 11. Maximum Values

Maximum demand values recorded starting from 100ms after closing of main Circuit Breaker (updated any time the breaker closes).

- Press "**Menu**" for access to the main menu with icons.
  
- Select "**MaxVal**" icon with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  
- Scroll the menu "**Measure**" with pushbutton "**Increase**" or "**Decrease**" to display the measurement.
  - Press "**Exit**" to go to the main menu.


<b>Imx</b>	(0 ÷ 99999)	<b>A</b>	Largest of the 3 phase-currents (Ia,Ib,Ic)
<b>Ia</b>	(0 ÷ 99999)	<b>A</b>	RMS value phase A current
<b>Ib</b>	(0 ÷ 99999)	<b>A</b>	RMS value phase B current
<b>Ic</b>	(0 ÷ 99999)	<b>A</b>	RMS value phase C current
<b>Io</b>	(0 ÷ 99999)	<b>A</b>	RMS value of Zero Sequence Current
<b>I1</b>	(0 ÷ 99999)	<b>In</b>	Positive sequence current
<b>I2</b>	(0 ÷ 99999)	<b>In</b>	Negative Sequence current
<b>Tem</b>	(0 ÷ 99999)	<b>%T</b>	Thermal status as % of the full load continuous operation temperature Tn


## 12. Trip Recording


Display of the function which caused the tripping of the relay plus values of the measurement at the moment of tripping. The last 30 events are recorded.


The memory buffer is refreshed at each new relay tripping (FIFO logic).


<i>Display</i>	→	Reading of recorded Trips.
<i>Erase</i>	→	Clear all Trips recorded.


- 

  - Press "**Menu**" for access to the main menu with icons.
  
- 

  - Select "**TripRec.**" icon with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  
- 

  - Select "**Display**" with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  - For "**Erase**" go to "8"
  
- 

  - If no trip is recorded the display shows "**No Trips**".
  
- 

  - If any trip was recorded, select "**View**" to display the chronological list of the records.
  - By the keys "**Increase**" or "**Decrease**" select the date of the record to be checked.
  
- 

  - Will be shown:
    - "**Descr**" the function that caused the event (Example: t1I> = Rise)
    - "**Edge**" if the function was tripped (Rise) or reset (Fall)
    - "**Date**", date of trip, year/month/day, hour:minutes:seconds:milliseconds
  - Press "**Value**", for reading the value of input quantities on tripping.

- 7**
- |   |                 |        |
|---|-----------------|--------|
|   | <b>TripRec.</b> | 1 - 7  |
| ▶ | Imx             | 1000 A |
|   | Ia              | 500 A  |
|   | Ib              | 500 A  |
|   | Ic              | 500 A  |
|   | Exit            |        |
- Scroll with pushbuttons "**Increase**" or "**Decrease**" the available measurements.
  - Select "**Exit**" to go back to "5" for another selection, or "2" go back to the main menu.
- 8**
- |   |                 |        |
|---|-----------------|--------|
|   | <b>TripRec.</b> | 2 - 2  |
|   | Display         |        |
| ▶ | Erase           |        |
|   | Exit            |        |
|   |                 | Select |
- Select "**Erase**" with button "**Decrease**".
  - Press "**Select**" to execute the commands; **All** Trips recorded are erased. (if Password is request, see § Password).
- 9**
- |  |                 |  |
|--|-----------------|--|
|  | <b>TripRec.</b> |  |
|  | Comand Done     |  |
- When command has been executed the display shows "**Command Done**";
  - Press "**Exit**" to go back to the main menu.





<i>Imx</i>	(0 ÷ 99999)	A	Largest of the 3 phase-currents (Ia,Ib,Ic)
<i>Ia</i>	(0 ÷ 99999)	A	RMS value phase A current
<i>Ib</i>	(0 ÷ 99999)	A	RMS value phase B current
<i>Ic</i>	(0 ÷ 99999)	A	RMS value phase C current
<i>Io</i>	(0 ÷ 99999)	A	RMS value of Zero Sequence Current (RMS Secondary Amps)
<i>I2</i>	(0 ÷ 99999)	In	Negative Sequence current
<i>Tem</i>	(0 ÷ 99999)	%T	Thermal status as % of the full load continuous operation temperature Tn

### 13. Partial Counters

Partial counters of the number of operations for each of the relay functions.

<b>Display</b> → <i>T&gt;</i>	0	Operations counters	Thermal Image
<i>1I&gt;</i>	0	Operations counters	First overcurrent element
<i>2I&gt;</i>	0	Operations counters	Second overcurrent element
<i>3I&gt;</i>	0	Operations counters	Third overcurrent element
<i>1Io&gt;</i>	0	Operations counters	First earth fault element
<i>2Io&gt;</i>	0	Operations counters	Second earth fault element
<i>3Io&gt;</i>	0	Operations counters	Third earth fault element
<i>1Is&gt;</i>	0	Operations counters	First negative sequence current element
<i>2Is&gt;</i>	0	Operations counters	Second negative sequence current element
<i>motST</i>	0	Operations counters	Motor Start
<i>mStOV</i>	0	Operations counters	Motor Start Overall counter
<i>LR</i>	0	Operations counters	Locked Rotor trip
<i>StNo</i>	0	Operations counters	Start number limitation trip
<i>StSeq</i>	0	Operations counters	Start Sequence trip
<i>I&lt;</i>	0	Operations counters	No Load running trip
<i>TCS</i>	0	Operations counters	Trip Circuit Supervision
<i>IRF</i>	0	Operations counters	Internal Relay Fault
<i>BrkF</i>	0	Operations counters	Breaker failure
<i>AutOp</i>	0	Operations counters	Automatic C/B Opening
<i>AutCL</i>	0	Operations counters	Automatic C/B Closing
<i>ManOp</i>	0	Operations counters	Manual C/B Opening
<i>ManCL</i>	0	Operations counters	Manual C/B Closing
<i>OvrOp</i>	0	Operations counters	Overall C/B Opening (Automatic + Manual)
<i>OvrCL</i>	0	Operations counters	Overall C/B Closing (Automatic + Manual)

**Erase** → Reset all Counters  
 (By the interface program software it is possible to individually reset the counters and set an initial starting number)

- 
  - Press "**Menu**" for access to the main menu with icons.
- 
  - Select "**Counter**" icon with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
- 
  - Select "**Display**" with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  - For "**Erase**" to go to "5"
- 
  - Display of the number of operations of each individual function.
  - With pushbuttons "**Increase**" or "**Decrease**" scroll the parameters
  - Press "**Exit**" go back to "3".




## 15. Events


Display of the function which caused any of the following events: - *Status change of digital Inputs/Outputs.* - *Start of protection functions* – *Trip of protection function* – *Function reset.*


The last 500 events are recorded at pick-up (rise) or drop-out (fall).


The memory buffer is updated at each new event.


<b>Display</b>	→	Reading events recorded.
<b>Erase</b>	→	Clear all events recorded.


- 


- Press "**Menu**" for access to the main menu with icons.
- 


- Select "**Events**" icon with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
- 

- Select "**Display**" with pushbutton "**Increase**" or "**Decrease**".
  - Press "**Select**" for access.
  - For "**Erase**" go to "7"
- 

- If no event is recorded the display shows message "**No Events**".
- 

- If any event was recorded, select "**View**" to display the chronological list of the records.
  - By the keys "**Increase**" or "**Decrease**" select the date of the record to be checked.
- 

- Will be shown:
    - "**Descr**" the function that caused the event (Example: 1I> = Start, t1I> = Trip)
    - "**Edge**" if the function was tripped (Rise) or reset (Fall)
    - "**Date**", date of trip, year/month/day, hour:minutes:seconds:milliseconds
- 

- Select "**Erase**" with button "**Decrease**".
  - Press "**Select**" to execute the commands; **All** Events recorded are erased. (if Password is request, see § Password).
- 

- When command has been execute the display shows "**Command Done**";
  - Press "**Exit**" to go back to the main menu.



## 15.1 – Events on display










Functions	Events Displayed			Events Description	Status
T>	Tal	Tal	Alarm	Thermal Image	Rise
	T>	T>	Trip		Fall
1I>	1I>	1I>	Start	Fist overcurrent element	Rise
	t1I>	t1I>	Trip		Fall
2I>	2I>	2I>	Start	Second overcurrent element	Rise
	t2I>	t2I>	Trip		Fall
3I>	3I>	3I>	Start	Third overcurrent element	Rise
	t3I>	t3I>	Trip		Fall
1Io>	1Io>	1Io>	Start	Fist earth fault element	Rise
	t1Io>	t1Io>	Trip		Fall
2Io>	2Io>	2Io>	Start	Second earth fault element	Rise
	t2Io>	t2Io>	Trip		Fall
3Io>	3Io>	3Io>	Start	Third earth fault element	Rise
	t3Io>	t3Io>	Trip		Fall
1Is>	1Is>	1Is>	Start	First negative sequence current	Rise
	t1Is>	t1Is>	Trip		Fall
2Is>	2Is>	2Is>	Start	Second negative sequence current	Rise
	t2Is>	t2Is>	Trip		Fall
TCS	TCS	TCS	Start	Trip Coil Supervision	Rise
	tTCS	tTCS	Trip		Fall
IRF	IRF	IRF	Start	Internal Relay Failure	Rise
	tIRF	tIRF	Trip		Fall
BF	BF	BF	Trip	Breaker Failure	Rise
LR	ILR	ILR	Start	Start Locked rotor	Rise
	tILR	tILR	Trip	Trip Locked rotor	Rise
StNo	LimStNum		Trip	Limitation of start number	Rise
StSeq	StSeqSucc		Start	Start sequence successful	Rise
	Itr		Start	Start sequence trip/switch over failure	Rise
I<	I<		Start	Start No load running protection	Rise
	tI<		Trip	Trip No load running protection	Fall
	MotON		Trip	Motor On	Rise
	Time Sincro		Trip	Time Sincronization	Fall
	DskClean			Disk near to full clean operation is required	Rise
	DskFull			Disk full write should be lock	Rise
	DskFRMT			Disk format in progress	Rise
Disk	rDskAttach	Not	Used	removable disk usb attach	Fall
	rDskDetach	Not	Used	removable disk usb detach	Rise
	rDskDtchable	Not	Used	removable disk usb now detachable	Rise
	rDskClean	Not	Used	Removable USB disk near to full clean oper. is required	Rise
	rDskFull	Not	Used	Removable disk USB full, write locked	Rise
	L/R disc			Local/Remote signal Discrepancy	Rise
	manOpKey			Circuit Breaker intentional open by key	Rise
	manOpLocC			Circuit Breaker intentional open by local command	Rise
	manOpRemC			Circuit Breaker intentional open by remote command	Rise
	manOpExtIn			Circuit Breaker intentional open by external input	Rise
C/B	ExterManOp			Circuit Breaker intentional external open	Rise
	manClKey			Circuit Breaker intentional close by key	Rise
	manClLocC			Circuit Breaker intentional close by local command	Rise
	manClRemC			Circuit Breaker intentional close by remote command	Rise
	manClExtIn			Circuit Breaker intentional close by external input	Rise
	ExterManCh			Circuit Breaker intentional external close	Rise
	CB-Fail			Circuit Breaker (C/B Failure)	Rise
	Gen.Trip			General Trip	Fall
	Gen.Start			General Start	Rise
Digital Inputs	0.D1			Digital Input D1	Rise
	to				Fall
	0.D8			Digital Input D8	Rise
	0.R1			Output relays R1	Fall
Output Relays	to				Rise
	0.R8			Output relays R8	Fall

## 16. System (System parameters)

Setting of system parameters.


<b>CTs&amp;PTs</b>	<b>Phase CT</b>	Primary	<b>Prim.</b>	→	1000	A	(1 ÷ 9999)	step	1	A
		Secondary	<b>Sec.</b>	→	1	A	(1 / 5)			
	<b>Neutral CT</b>	Primary	<b>Prim.</b>	→	1000	A	(1 ÷ 9999)	step	1	A
		Secondary	<b>Sec.</b>	→	1	A	(1 / 5)			
	<b>Sys.Ratings</b>		<b>Fn</b>	→	50	Hz	(50 / 60)			
			Nominal Frequency							
			<b>In</b>	→	100	A	(1 ÷ 9999)	step	1	A
		Nominal Current								

<b>Setting Group</b>	<b>Group</b>	→	1	(1 / 2)
----------------------	--------------	---	---	---------


- 
  - Press **"Menu"** for access to the main menu with icons.
- 
  - Select **"System"** icon with pushbuttons **"Increase"** or **"Decrease"**.
  - Press **"Select"** for access.
- 
  - Select **"CTs&PTs"**.
  - Press **"Select"** for access.
- 
  - Select **"Phase CT"**.
  - Press **"Select"** for access.
- 
  - Select **"Primary"** to modify the value, or press **"Decrease"**
  - Press **"Modify"** to modify the parameter.  
(if Password is request, see § Password).
- 
  - Appear  icon.
  - Use pushbuttons **"Increase"** or **"Decrease"** to set the value.
  - Press **"Write"** to confirm the value
- 
  - The value is now set.
  - To set a new value return to the point "4".
  - Press **"Exit"**.
- 
  - The display show **"Confirm the change?"**.
  - Choose **"Yes"** to confirm the changes.
  - Choose **"No"** to **not** confirm the changes.
  - After set confirmation (or non-confirmation) the display goes back to point "3".

## 17. Settings

Two complete banks of settings of the programmable variables are available in the “**SETTING**” menu. Both “Group #1” and “Group #2” include the hereunder listed variables.

**1**  **Setting** 1 - 20

- Communic
- Customize
- FileSys
- T>

Exit  Select

**1** Indicates the Setting Group that is actually being modified.













---

This symbol indicates that the function aside is enabled; symbol missing indicates that the function is disabled.

Group#1	Group#2	Descriptions
<i>Communic.</i>	<i>Communic.</i>	Serial communication parameters
<i>Customise</i>	<i>Customise</i>	Visualization parameters
<i>FileSys</i>	<i>FileSys</i>	File Systems and disks management
<i>T&gt;</i>	<i>T&gt;</i>	Thermal Image
<i>1I&gt;</i>	<i>1I&gt;</i>	First Overcurrent Element
<i>2I&gt;</i>	<i>2I&gt;</i>	Second Overcurrent Element
<i>3I&gt;</i>	<i>3I&gt;</i>	Third Overcurrent Element
<i>1Io&gt;</i>	<i>1Io&gt;</i>	First Earth Fault Element
<i>2Io&gt;</i>	<i>2Io&gt;</i>	Second Earth Fault Element
<i>3Io&gt;</i>	<i>3Io&gt;</i>	Third Earth Fault Element
<i>1Is&gt;</i>	<i>1Is&gt;</i>	First Negative Sequence Current Element
<i>2Is&gt;</i>	<i>2Is&gt;</i>	Second Negative Sequence Current Element
<i>MotSt</i>	<i>MotSt</i>	Motor Start
<i>LR</i>	<i>LR</i>	Locked rotor protection
<i>StNo</i>	<i>StNo</i>	StartNumber limitation tripping
<i>StSeq</i>	<i>StSeq</i>	Starting sequence Control
<i>I&lt;</i>	<i>I&lt;</i>	No Load running protection
<i>TCS</i>	<i>TCS</i>	Setting variables for Trip Circuit Supervision
<i>IRF</i>	<i>IRF</i>	Internal Relay Fault
<i>BrkFail</i>	<i>BrkFail</i>	Setting variables for Breaker Failure detection
<i>Oscillo</i>	<i>Oscillo</i>	Setting variables for Oscillographic recording
<i>CB-Mngn</i>	<i>CB-Mngn</i>	C/B command Local / Remote setting
<i>ExtReset</i>	<i>ExtReset</i>	Configuration for external reset input

*17.1 - Modifying the setting of variables*

To modify any variable setting by the keyboard proceed as follows:  
 (example: change setting of element "1I>", from "Is 1.000 In" to "Is 3.500 In")

- |   |  |   |   |
|---|--|---|---|
| <p><b>1</b></p>    | <ul style="list-style-type: none"> <li>Press "<b>Menu</b>" for access to the main menu with icons.</li> </ul>  | <p><b>7</b></p>     | <ul style="list-style-type: none"> <li>Appear  icon.</li> </ul>          |
| <p><b>2</b></p>    | <ul style="list-style-type: none"> <li>Select icon "<b>Setting</b>" by pushbuttons "<b>Increase</b>" or "<b>Decrease</b>".</li> <li>Press "<b>Select</b>".</li> </ul>                                    | <p><b>8</b></p>     | <ul style="list-style-type: none"> <li>Set new values pushbuttons "<b>Increase</b>" or "<b>Decrease</b>" buttons.</li> <li>Press "<b>Write</b>".</li> </ul> |
| <p><b>3</b></p>    | <ul style="list-style-type: none"> <li>Select by pushbuttons "<b>Group#1</b>".</li> <li>Press "<b>Select</b>".</li> </ul>  | <p><b>9</b></p>     | <ul style="list-style-type: none"> <li>If the change of parameters is completed, press "<b>Exit</b>".</li> </ul>  |
| <p><b>4</b></p>   | <ul style="list-style-type: none"> <li>Select by pushbuttons "<b>Increase</b>" or "<b>Decrease</b>" the parameter "<b>1I&gt;</b>".</li> <li>Press "<b>Select</b>".</li> </ul>                            | <p><b>10</b></p>   | <ul style="list-style-type: none"> <li>"<b>Yes</b>" confirm all changes.</li> <li>"<b>No</b>" voids all the changes.</li> </ul>                             |
| <p><b>5</b></p>  | <ul style="list-style-type: none"> <li>Select by buttons "<b>Increase</b>" or "<b>Decrease</b>" the menu "<b>Oper.Levels</b>".</li> <li>Press "<b>Select</b>".</li> </ul>                                | <p><b>11</b></p>  | <ul style="list-style-type: none"> <li>The relay returns to point "<b>4</b>".</li> </ul>  |
| <p><b>6</b></p>  | <ul style="list-style-type: none"> <li>The arrow aside "<b>Is</b>" shows the parameter selected for changing.</li> <li>Press "<b>Modify</b>".</li> <li>If Password is request, see § Password</li> </ul> |   |   |

17.2 - Password

The password is requested any time the user wishes to modify any password protected parameter (example "1I>" menu "Setting").

The factory default password is "1111".


The password is only modifiable with the software.

When password is requested, proceed as follows:

- |          |  |  |          |  |   |
|----------|--|--|----------|--|---|
| <b>1</b> |  | Use the key " <b>Increase</b> " and " <b>Decrease</b> " and set the first digit of password. | <b>5</b> |  | Use the key " <b>Increase</b> " or " <b>Decrease</b> " to set the third digit.  |
| <b>2</b> |  | Press " <b>Next</b> " to validate and go to the next digit.                                  | <b>6</b> |  | Press " <b>Next</b> " to validate and go to the next digit.                     |
| <b>3</b> |  | Use the key " <b>Increase</b> " or " <b>Decrease</b> " to set second digit.                  | <b>7</b> |  | Use the key " <b>Increase</b> " or " <b>Decrease</b> " to set the fourth digit. |
| <b>4</b> |  | Press " <b>Next</b> " to validate and go to the next digit.                                  | <b>8</b> |  | Press " <b>Next</b> " to validate and go to modify the next parameter.          |

By key "**Prev**" go back to previous digit.

The password validity expires 60 sec after the last setting modification or as soon as you go back to the main menu



- |          |  |  |          |  |   |
|----------|--|--|----------|--|---|
| <b>1</b> |  | If set the incorrect password the display shows " <b>Wrong code</b> ". | <b>2</b> |  | The display will repeat the initial interrogation |
|----------|--|--|----------|--|---|

17.3 – Menu: **Communic.** (Communication)

Options	→ <b>BRRem</b>	19200	[9600 / 19200 / 38400]
	→ <b>PRRem</b>	MODBUS	[MODBUS / IEC103]
Node Address	→ <b>Addr.</b>	1	[1 ÷ 250]

17.3.1 – Description of variables

<b>BRRem</b>	: USB (Front Panel) serial communication speed
<b>PRRem</b>	: Remote Protocol
<b>Addr.</b>	: Identification number for the connection on serial communication bus

17.3.2 – Front Panel USB serial communication port (RS232)

A Mini-USB socket is available on Relay’s front face for connection. Through this port - and by the interface program for Windows XP Pro (SP3)/7/10 – it is possible connect a Personal Computer to download all available information, operate any control and program the relay; the protocol used is “Modbus RTU”.

17.3.3 – Cable for connection from Relay to Personal Computer

The connection cable is a standard USB-A/mini USB-B



**USB type-A**

**USB type-B**

17.3.4 – Main serial communication port (RS485)

From the Relay’s back terminal board, a RS485 ports is available for communication with SCADA system with Protocol Modbus RTU or IEC60870-5-103 (selectable). The communication interface allows to program all settings, operate all commands and download all information and records. The physical connection can be via a normal pair of wires (RS485).

17.4 - Menu: **Customize** (Human Machine Interface)

Options	→	Lang	English	[English / Loc.Lang]
	→	Light	On	[Auto / On]
Timers	→	tBckL	20	s (5 ÷ 120) step 1 s









17.4.1 - Description of variables

Lang	:	Set Language
Light	:	Set Display backlight
tBckL	:	Set Display backlight time

This menu allows to customize the Language and the Display.

The Display backlight can be programmed always on "ON" or switched-on "Automatically" for a few second (set parameter "tBckL") at any operation of the keyboard.

*Example: set Local Language.*

- 
  - Press "**Menu**" for access to the main menu with icons.
- 
  - Select icon "**Setting**" by pushbuttons "**Increase**" or "**Decrease**".
  - Press "**Select**".
- 
  - Select "**Group 1**" or "**Group 2**".
  - Select "**Customize**".
  - Select "**Options**".
  - Press "**Select**".
- 
  - Select "**Lang**".
  - Press "**Modify**".
- 
  - Select "**Loc.Lang**".
  - Press "**Write**".
  - If Password is requested, see § Password
- 
  - Press "**Exit**".
- 
  - "**Yes**" confirms all changes.
  - "**No**" void all changes.
- 
  - After set confirmation the display shows "**Please Wait**".

17.5 - Function: **FileSys** (File system and Disk management)

Options	→ <b>log</b>	disable	[disable / int.disk]
	→ <b>OniDF</b>	StopWrite	[StopWrite / DelOldFiles]




17.5.1 - Description of variables

<b>log</b>	:	Internal Disk write
	<i>Enable</i>	: Protection log file write enabled
	<i>Disable</i>	: Protection log file write disabled
<b>OniDF</b>	:	Write policy on internal full disk condition
	<i>StopWrite</i>	: Write disable
	<i>DelOldFiles</i>	: Delete older folder and write

17.5.2 - Download file informations

Files related to "Journal" - "Fault log" - "Oscillo" are available in the relay internal memory.

Connect the USB cable to the relay and wait a few moments.

Through the "Computer  " icon on your desktop to access disk management, select the relay hard drive on recording equipment "  "  " .

17.5.2.1 - Journal file

Example:

Directory		Descriptions	
<b>DATALOG</b>	2018	Year	
	Jul	Month	
	08	Day	
	Jrnl_08.07.2018.txt	Journal File	

Jrnl_08.07.2018.txt			
Date	Time	Event	
2018/07/03	18:42:07:100	Vcc	Rise
2018/07/03	18:42:07:100	L/Rdisc	Rise
2018/07/03	18:42:07:110	IPU boot	Rise

17.5.2.2 - Faults log file

Example:

Directory		Descriptions	
<b>TRIPS</b>	2018	Year	
	Jul	Month	
	15	Day	
	Trips_15.06.2018.txt	Trips log File	

Trips_15.06.2018.txt			
Date	Time	Event	Values
2018/06/15	08:17:27:200	tTCS	Imx=0.0; Ia=0.0; Ib=0.0; Ic=0.0; Io=0.0; I2=0.00; Tem=0
2018/06/15	10:31:03:901	tTCS	Imx=0.0; Ia=0.0; Ib=0.0; Ic=0.0; Io=0.0; I2=0.00; Tem=0

17.5.2.3 - Oscillographic file

Example:

Directory		Descriptions	
<b>OSCILLO</b>	2018	Year	
	Jul	Month	
	18	Day	
	fault1_2016.05.08.15.56.45.cfg	Oscillographic Comtrade	
	fault1_2016.05.08.15.56.45.dat	File	

**17.6 - Function: T> (Thermal Image F49)**

<b>Status</b>	→ <b>Enab.</b>	No	[No / Yes]				
<b>Options</b>	→ <b>OPMOD</b>	I1.I2	[I1.I2 / I.Max]				
<b>Livelli</b>	→ <b>Tal</b>	50	%Tb	[10 ÷ 100]	step	1	%Tb
	→ <b>Is</b>	1	In	[0.5 ÷ 1.5]	step	0.01	In
	→ <b>Tres</b>	50	%Tb	[10 ÷ 100]	step	1	%Tb
	→ <b>To</b>	1	nkt	[1 ÷ 10]	step	1	nkt

**17.6.1 - Description of variables**

<b>Abil.</b>	: Function enabling (No = Disable / Yes = Enable)
<b>OPMOD</b>	: <b>I1.I2</b> = Direct/Inverse current <b>I.Max</b> = Phase current
<b>Tal</b>	: Temperature pre-alarm level
<b>Is</b>	: Continuous admissible current
<b>Tres</b>	: Temperature reset
<b>To</b>	: Warming-up Time Constant of the load

**17.6.2 - Trip and Alarm**

The algorithm compares the amount of heat accumulated "T" ( $\equiv i^2 \cdot t$ ) to the steady state amount of heat "Ts" corresponding to continuous operation at the continuously admissible current "Is".  
When the ratio "T/Ts" reaches the level set for Thermal Alarm "Tal" of the max allowed heating, the relay trips accordingly

**17.6.2.1 - Trip time of the Thermal Image Element**


The trip time of the Thermal Image Element is a function of the current "I" flowing into the load and depends on its warming-up Time Constant "Kt", on the previous thermal status "Ip" and on the maximum admissible continuous current "Is" according to the equation:

<b>t</b>	= Time to relay tripping
<b>Kt</b>	= Load thermal time constant
<b>I</b>	= Actual load current
<b>In</b>	= Load rated current
<b>Is</b>	= Continuous admissible current
<b>Ip</b>	= Steady state current before the overload
<b>ln</b>	= Natural Logarithm

$$t = Kt \cdot \ln \frac{\left(\frac{I}{In}\right)^2 - \left(\frac{Ip}{In}\right)^2}{\left(\frac{I}{In}\right)^2 - \left(\frac{Is}{In}\right)^2}$$

When the heating exceeds the set alarm level "Tal" or the max. allowed level ("I" > "Is" for the time "t") the output relays programmed for these function will be operated. Reset will take place when the thermal status will drop below 95% of the trip level.

## 17.6.2.2 - Thermal Image Curves (TU1024 Rev.1)



17.7 - Function: **1I**> (First Overcurrent Element F50/51)

Status	→	<b>Enab.</b>	No		[No / Yes]
Options	→	<b>f(t)</b>	Type - D		[D / A / B / C / I / VI / EI / MI / SI ]
	→	<b>tBI</b>	Off		[Off / 2tBO]
Oper. Levels	→	<b>Is</b>	1	In	(0.1 ÷ 4) step 0.01 In
Timers	→	<b>ts</b>	100	s	(0.02 ÷ 100) step 0.01 s
	→	<b>tBO</b>	0.75	s	(0.05 ÷ 0.75) step 0.01 s

## 17.7.1 - Description of variables

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>f(t)</b>	:	Operation characteristic (Time/Current curve):
		(D) = Independent definite time
		(A) = IEC Inverse Curve type A
		(B) = IEC Very Inverse Curve type B
		(C) = IEC Extremely Inverse Curve type C
		(I) = IEEE Inverse Curve
		(VI) = IEEE Very Inverse Curve
		(EI) = IEEE Extremely Inverse Curve
		(MI) = IEEE Moderate Inverse Curve
		(SI) = IEEE Short Inverse Curve
<b>tBI</b>	:	Blocking input reset time
		Off = Permanent block
		2tBO = Set 2xtBO.
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

### 17.7.2 - Blocking Logic (BO-BI)

For each Protection Function it is possible to activate a Blocking Logic allowing for inhibiting their operation by external signals supplied to the Digital Input.

#### 17.7.2.1 - Output Blocking signal "BO"

All the protection functions that can be programmed to operate in the blocking logic mode, element, have an instantaneous element (beside the time delayed) which is operated as soon as the controlled quantity exceeds the set trip level ( $I > [I_s]$  for current, etc..) and is instantaneously reset when the input quantity drops below the reset level (normally  $0.95I_s$ ).

The instantaneous element can control one of the user programmable output relays that, by its contacts, makes the signal available for blocking an external element (BO = Blocking Output).

In case, "tBO" sec after the set trip time "ts" has expired, the Protection function is still in operation (current above trip level), the Blocking Output relay (instantaneous element) is anyhow reset to eventually remove the Blocking signal from a back-up protection.

#### 17.7.2.2 - Blocking Input "BI"

For all the functions controllable by the Blocking Logic, it is possible to inhibit the time delayed tripping by an external signal that activates a Digital Input programmed for this functionality.

The programmed Digital Input gets activated by an external cold contact closing across its terminals.

With the variable "tBI" set to "OFF" ( $tBI=OFF$ ), the tripping of the delayed function is blocked as long as the Blocking Input signal is present at the terminals of the Digital Input.

With the variable "tBI" set to "2xtBI" ( $tBI=2xtBI$ ), 2xtBI seconds after the set trip time delay of the function has expired the blocking input is anyhow ignored and the function enabled to trip.

### 17.7.3 - Automatic doubling of Overcurrent thresholds on current inrush

For some of the phase Overcurrent functions it is possible to have the set trip level  $[I_s]$  automatically doubled when strong inrush current is detected.

If at circuit Breaker switch-on (i.e. when the input current rises from zero to a minimum measurable value) the current increases from 0 to 1.5 times the rated value  $[I_n]$  in less than 60ms, the set minimum pick-up level  $[I_s]$  is dynamically doubled ( $[I_s] \rightarrow [2I_s]$ ) and keeps this value until the input current drops below  $1.25xI_n$  or the set time  $[t_{2xI}]$  has elapsed.

This functionality is very useful to avoid spurious tripping of the instantaneous, or short-time delayed Overcurrent elements, that could be experienced at switch-on when energizing the feeder.

**17.8 - Function: 2I> (Second Overcurrent Element F50/51)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]
<b>Options</b>	→ <b>tBI</b>	Off		[Off / 2tBO]
	→ <b>2xI</b>	Disable		[Disable / Enable]
<b>Oper. Levels</b>	→ <b>Is</b>	1	In	(0.1 ÷ 40) step 0.01 In
<b>Timers</b>	→ <b>ts</b>	100	s	(0.02 ÷ 100) step 0.01 s
	→ <b>tBO</b>	0.75	s	(0.05 ÷ 0.75) step 0.01 s
	→ <b>t2xI</b>	2	s	(0.02 ÷ 100) step 0.01 s

**17.8.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>tBI</b>	:	Blocking input reset time Off = Permanent block 2tBO = Set 2xtBO.
<b>2xI</b>	:	Automatic doubling of trip level on inrush
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.
<b>t2xI</b>	:	Maximum time of automatic threshold doubling on inrush

**17.9 - Function: 3I> (Third Overcurrent Element F50/51)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]
<b>Options</b>	→ <b>tBI</b>	Off		[Off / 2tBO]
	→ <b>2xI</b>	Disable		[Disable / Enable]
<b>Oper. Levels</b>	→ <b>Is</b>	1	In	(0.1÷40) step 0.01 In
<b>Timers</b>	→ <b>ts</b>	5	s	(0.02÷100) step 0.01 s
	→ <b>tBO</b>	0.75	s	(0.05÷0.75) step 0.01 s
	→ <b>t2xI</b>	2	s	(0.02÷100) step 0.01 s

**17.9.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>tBI</b>	:	Blocking input reset time Off = Permanent block 2tBO = Set 2xtBO.
<b>2xI</b>	:	Automatic doubling of trip level on inrush
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.
<b>t2xI</b>	:	Maximum time of automatic threshold doubling on inrush

**17.10 - Function: 1Io> (First Earth Fault Element 50N/51N)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]
<b>Options</b>	→ <b>f(t)</b>	Type - D		[D / A / B / C / I / VI / EI / MI / SI]
	→ <b>tBI</b>	Off		[Off / 2tBO]
<b>Oper.Levels</b>	→ <b>Is</b>	0.01	On	(0.01 ÷ 4) step 0.01 On
<b>Timers</b>	→ <b>ts</b>	100	s	(0.02 ÷ 100) step 0.01 s
	→ <b>tBO</b>	0.75	s	(0.05 ÷ 0.75) step 0.01 s

On = Rated primary current of CTs or of the current Tore CT.

**17.10.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>f(t)</b>	:	Operation characteristic (Time/Current curve):
		(D) = Independent definite time
		(A) = IEC Inverse Curve type A
		(B) = IEC Very Inverse Curve type B
		(C) = IEC Extremely Inverse Curve type C
		(I) = IEEE Inverse Curve
		(VI) = IEEE Very Inverse Curve
		(EI) = IEEE Extremely Inverse Curve
		(MI) = IEEE Moderate Inverse Curve
		(SI) = IEEE Short Inverse Curve
<b>tBI</b>	:	Blocking Input reset time
		Off = Permanent block
		2tBO = Set 2xtBO.
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

**17.11 - Function: 2Io> (Second Earth Fault Element 50N/51N)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]
<b>Options</b>	→ <b>tBI</b>	Off		[Off / 2tBO]
<b>Oper.Levels</b>	→ <b>Is</b>	0.01	On	(0.01 ÷ 9.99) step 0.01 On
<b>Timers</b>	→ <b>ts</b>	100	s	(0.02 ÷ 100) step 0.01 s
	→ <b>tBO</b>	0.75	s	(0.05 ÷ 0.75) step 0.01 s

On = Rated primary current of CTs or of the current Tore CT.

**17.11.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>tBI</b>	:	Blocking Input reset time
		Off = Permanent block
		2tBO = Set 2xtBO.
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.



17.12 - Function: **3Io>** (Third Earth Fault Element 50N/51N)

<i>Status</i>	→ <i>Enab.</i>	Yes		[No / Yes]			
<i>Options</i>	→ <i>tBI</i>	Off		[Off / 2tBO]			
<i>Oper.Levels</i>	→ <i>Is</i>	0.01	<i>On</i>	(0.01÷9.99)	step	0.01	On
<i>Timers</i>	→ <i>ts</i>	100	<i>s</i>	(0.02÷100)	step	0.01	s
	→ <i>tBO</i>	0.75	<i>s</i>	(0.05÷0.75)	step	0.01	s

On = Rated primary current of CTs or of the current Tore CT.

17.12.1 - Description of variables

<i>Enab.</i>	: Function enabling (No = Disable / Yes = Enable)
<i>tBI</i>	: Blocking Input reset time
	<i>Off</i> = Permanent block
	<i>2tBO</i> = Set 2xtBO.
<i>Is</i>	: Minimum operation level
<i>ts</i>	: Trip time delay
<i>tBO</i>	: Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

**17.13 - Function: 1Is> (First Negative Sequence Element F46)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]				
<b>Options</b>	→ <b>t(t)</b>	Type-D		[D / A / B / C / I / VI / EI / MI / SI]				
	→ <b>tBI</b>	Off		[Off / 2tBO]				
<b>Oper.Levels</b>	→ <b>Is</b>	4	In	(0.1 ÷ 4)	step	0.01	In	
<b>Timers</b>	→ <b>ts</b>	100	s	(0.02 ÷ 100)	step	0.01	s	
	→ <b>tBO</b>	0.75	s	(0.05 ÷ 0.75)	step	0.01	s	

**17.13.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>f(t)</b>	:	Operation characteristic (Time/Current curve):
		(D) = Independent definite time
		(A) = IEC Inverse Curve type A
		(B) = IEC Very Inverse Curve type B
		(C) = IEC Extremely Inverse Curve type C
		(I) = IEEE Inverse Curve
		(VI) = IEEE Very Inverse Curve
		(EI) = IEEE Extremely Inverse Curve
		(MI) = IEEE Moderate Inverse Curve
		(SI) = IEEE Short Inverse Curve
<b>tBI</b>	:	Blocking Input reset time
		Off = Permanent block
		2tBO = Set 2xtBO.
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

**17.13.2 - Time/Current operation of the first Current Unbalance element "f(t)"**

The relay measures the Negative Sequence component "I2" of the input current.  
The Time/Current curves can be selected by programming the variable "f(t)":

f(t) = D	Independent definite time operation.
f(t) = I, VI, EI, MI, SI, A, B, C	Dependent Inverse time operation

**17.14 - Function: 2Is> (Second Negative Sequence Element F46)**

<b>Status</b>	→ <b>Enab.</b>	Yes		[No / Yes]				
<b>Options</b>	→ <b>tBI</b>	Off		[Off / 2tBO]				
<b>Oper.Levels</b>	→ <b>Is</b>	4	In	(0.1 ÷ 4)	step	0.01	In	
<b>Timers</b>	→ <b>ts</b>	100	s	(0.02 ÷ 100)	step	0.01	s	
	→ <b>tBO</b>	0.75	s	(0.05 ÷ 0.75)	step	0.01	s	

**17.14.1 - Description of variables**

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>tBI</b>	:	Blocking Input reset time
		Off = Permanent block
		2tBO = Set 2xtBO.
<b>Is</b>	:	Minimum operation level
<b>ts</b>	:	Trip time delay
<b>tBO</b>	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

17.15 - Function: **MotSt** (Motor Start)

Oper.Levels	→ <i>Im</i>	0.1	In	(0.05 ÷ 1)	step	0.01	In
Timers	→ <i>tfst</i>	0.1	s	(0.02 ÷ 1)	step	0.01	s
	→ <i>tst</i>	120	s	(10 ÷ 120)	step	0.01	s

## 17.15.1 - Description of variables

<i>Im</i>	:	Minimum operation level
<i>tfst</i>	:	Motor start filter time
<i>tst</i>	:	Motor starting time; 2xtst Inhibition time of the locked rotor function

17.16 - Function: **LR** (Locked Rotor – Rotor jam)

Status	→ <i>Enab.</i>	Yes		[No / Yes]			
Oper.Levels	→ <i>ILR</i>	1	In	(1 ÷ 5)	step	0.01	In
Timers	→ <i>tLR</i>	120	s	(1 ÷ 120)	step	0.01	s

## 17.16.1 - Description of variables

<i>Enab.</i>	:	Function enabling (No = Disable / Yes = Enable)
<i>ILR</i>	:	Minimum operation level
<i>tLR</i>	:	Trip time delay

17.17 - Function: **StNo** (Limitation Start Number)

Status	→ <i>Enab.</i>	Yes		[No / Yes]			
Oper.Levels	→ <i>StNo</i>	10	In	(1 ÷ 60)	step	1	
Timers	→ <i>tstNo</i>	600	s	(60 ÷ 3600)	step	60	s
	→ <i>tBst</i>	600	s	(60 ÷ 3600)	step	60	s

## 17.17.1 - Description of variables

<i>Enab.</i>	:	Function enabling (No = Disable / Yes = Enable)
<i>StNo</i>	:	Maximum number of starting allowed within te time tStNo
<i>tstNo</i>	:	Time in to which the StNo is counted
<i>tBst</i>	:	Restart inhibition time after tripping StNo

17.18 - Function: **StSeq** (starting Sequence Control)

Status	→ <i>Enab.</i>	Yes		[No / Yes]			
Oper.Levels	→ <i>I<sub>Tr</sub></i>	10	In	(0.1 ÷ 1)	step	0.1	In
Timers	→ <i>t<sub>Tr</sub></i>	20	s	(0.5 ÷ 50)	step	0.1	s

17.18.1 - Description of variables

<i>Enab.</i>	: Function enabling (No = Disable / Yes = Enable)
<i>I<sub>Tr</sub></i>	: Switch-over current of motor starter
<i>t<sub>Tr</sub></i>	: Trip time delay of LR during run

17.18.2 - Operation

During start-up of the motor, the unit can control an output relay used to operate the switch-over of motor starter (star-delta, resistance or impedance, autotransformer, etc...) thus allowing to automatically manage the starting transition by controlling the parameters "I<sub>Tr</sub>", "t<sub>Tr</sub>".

At motor start counting of "t<sub>Tr</sub>" begins. If during "t<sub>Tr</sub>" the motor current drops below "I<sub>Tr</sub>", switching-over is operated; if motor current stays above "I<sub>Tr</sub>" longer than "t<sub>Tr</sub>", the Locked Rotor element is activated.

17.19 - Function: **I<** (No load running)

Status	→ <i>Enab.</i>	No		[No / Yes]			
Oper.Levels	→ <i>I&lt;</i>	0.5	In	(0.15 ÷ 1)	step	0.01	In
Timers	→ <i>tI&lt;</i>	30	s	(0.1 ÷ 90)	step	0.01	s

17.19.1 - Description of variables

<i>Enab.</i>	: Function enabling (No = Disable / Yes = Enable)
<i>I&lt;</i>	: Operation level
<i>tI&lt;</i>	: Trip time delay

17.19.2 - Operation

This function performs the protection against no-load running: it is activated by motor under current.

17.20 - Function: **TCS** (Trip Circuit Supervision)

Status	→ <i>Enab.</i>	No	[No / Yes]
Timers	→ <i>ts</i>	0.1 s	(0.1 ÷ 100) step 0.01 s

18.20.1 - Description of variables

- Enab.* : Function enabling (No = Disable / Yes = Enable)
- ts* : Trip time delay


17.20.2 - Operation

The relay includes a complete Circuit Breaker Trip Circuit Supervision unit that is associated to the Contact "9-10" of the "R1" Output Relay.  
 The contact of "R1" is used to trip the C/B as reported in the drawing here below.  
 The supervision works when the C/B is closed and recognizes the Trip Circuit as sound as far as the current flowing exceeds "1mA".  
 In case of Trip Circuit Fault detection, the diagnostic relay is operated and the Led starts flashing (see § Signalization).  
 To have Supervision also with the C/B open one N/C contact (52b) from the C/B and an external resistor "R" are needed.

$$R[k\Omega] \leq \frac{V}{1mA} - R_{52} \quad \text{where } R_{52} = \text{Trip Coil internal resistance } [k\Omega]$$

$V = \text{Trip Circuit Voltage}$

$$P_R \geq 2 \cdot \frac{V^2}{R} [W] \quad \text{Designed power of external resistance "R"}$$



Tripping of the function operates a user programmable output relay.



### 17.21 - Function: **IRF** (Internal Relay Fault)

In this menu it is possible to configurate the operation of the Relay Internal Fault detection element

Status	→	<i>Enab.</i>	No		[No / Yes]
Timers	→	<i>tIRF</i>	5	s	(5 ÷ 200) step 0.01 s

#### 17.21.1 - Description of variables

<i>Enab.</i>	:	Function enabling (No = Disable / Yes = Enable)
<i>tIRF</i>	:	Trip time delay

#### 17.21.2 - Operation

Tripping of the function operates a user programmable output relay.

### 17.22 - Function: **BrkFail** (Breaker Failure)

Status	→	<i>Enab.</i>	No		[No / Yes]
Timers	→	<i>tBF</i>	0.75	s	(0.05 ÷ 0.75) step 0.01 s

#### 17.22.1 - Description of variables

<i>Enab.</i>	:	Function enabling (No = Disable / Yes = Enable)
<i>tBF</i>	:	Trip time delay

#### 17.22.2 - Operation

The Breaker Failure detection is started by the operation of the output relay "R1", (programmed to be controlled by the Protection Functions that trip the C/B).  
If after [tBF] seconds from operation of the relay "R1", any input current flow is still detected (>10% In), the function "BF" trips and operate one user programmable output relay,



### 17.23 - Function: **Oscillo** (Oscillographic Recording)

<b>Status</b>	→ <b>Enab.</b>	No	[No / Yes]
<b>Options</b>	→ <b>Trig</b>	Trip	[Start / Trip / OnCmd / REUserLg / FEUserLg]
<b>Timers</b>	→ <b>tPre</b>	0.5	s (0.01 ÷ 2) step 0.01 s
	→ <b>tPost</b>	0.5	s (0.01 ÷ 8) step 0.01 s

#### 17.23.1 - Description of variables

<b>Enab.</b>	:	Function enabling (No = Disable / Yes = Enable)
<b>Trig</b>	:	Selection of the Trigger command source (start recording):
		<i>Start</i> = Trigger on time start of protection functions
		<i>Trip</i> = Trigger on trip (time delay end) of protection functions
		<i>OnCmd</i> = On Asynchronous Force trigger command
		<i>REUserLg</i> = On rising edge of "User Logic" (see § "User Trigger Oscillo")
		<i>FEUserLg</i> = On falling edge of "User Logic"
<b>tPre</b>	:	Recording time before Trigger
<b>tPost</b>	:	Recording time after Trigger

#### 17.23.2 - Operation

In the options: "Trig = Start" and "Trig = Trip", the oscillographic recording starts respectively when any protection function starts operating or trip.

The "Oscillo" Function includes the oscillographic recorder of input quantities able to store up to 10 seconds for each record.

The number of events recorded depends on the duration of each individual recording (tPre + tPost).

In any case the number of event stored can not exceed 40 (40 x 1 sec).

Any new event exciting the memory capability, cancels and overwrites the former records.

Example:

<i>tPre</i>	=	0.5s	=	1s	→	40	Oscillographic recording
<i>tPost</i>	=	0.5s					
<i>tPre</i>	=	2s	=	10s	→	4	Oscillographic recording
<i>tPost</i>	=	8s					

## 17.23.3 – Available on software

Internal Disk	<i>DskClean</i>		Disk near Full clean operation is required	
	<i>DskFull</i>		Disk Full Write should be lock	
Removable Disk	<i>DskWR</i>		Disk write in progress	
	<i>DskFRMT</i>		Disk Format in progress	
	<i>DskCHK</i>		Check disk in progress	
	<i>rDskAttach</i>		Removable disk usb attach	
	<i>rDskDetach</i>		Removable disk usb detach	
	<i>rDskDtachable</i>		Removable disk usb now detachable	
	<i>rDskClean</i>		Removable disk usb near to full clean operation is required	
	<i>rDskFull</i>		Removable disk usb full, write locked	
	<i>rDskWR</i>		Removable disk usb write in progress	
	<i>rDskFRMT</i>		Removable disk usb format in progress	
<i>rDskCHK</i>		Removable disk usb check in progress		
T>	<i>Tal</i> <i>T&gt;</i>	Alarm Trip	Thermal Image T>	
1I>	<i>1I&gt;</i> <i>t1I&gt;</i>	Start Trip	First overcurrent element F50-51	
2I>	<i>2I&gt;</i> <i>t2I&gt;</i>	Start Trip	Second overcurrent element F50-51	
3I>	<i>3I&gt;</i> <i>t3I&gt;</i>	Start Trip	Third overcurrent element F50-51	
1Io>	<i>1Io&gt;</i> <i>t1Io&gt;</i>	Start Trip	First earth fault element F50N-51N	
2Io>	<i>2Io&gt;</i> <i>t2Io&gt;</i>	Start Trip	Second earth fault element F50N-51N	
3Io>	<i>3Io&gt;</i> <i>t3Io&gt;</i>	Start Trip	Third earth fault element F50N-51N	
1Is>	<i>1Is&gt;</i> <i>t1Is&gt;</i>	Start Trip	First negative sequence current element F46	
2Is>	<i>2Is&gt;</i> <i>t2Is&gt;</i>	Start Trip	Second negative sequence current element F46	
LR	<i>Mot On</i>		Motor Start	
	<i>ILR</i>	Start	Start Locked rotor	
	<i>tILR</i>	Trip	Trip Locked rotor	
	<i>LimStNum</i>	Trip	Limitation of start number	
Itr	<i>StSeqSucc</i>	Start	Start sequence successful	
	<i>Itr</i>	Trip	Switch-over current	
I<	<i>I&lt;</i> <i>tI&lt;</i>	Trip Start	No Load Running protection	
BF	<i>BF</i>	Trip	Breaker Failure	
TCS	<i>TCS</i>	Start	trip coil supervision	
	<i>tTCS</i>	Trip		
IRF	<i>IRF</i>	Start	Internal Relay Failure	
	<i>tIRF</i>	Trip		
C/B	<i>manOpCmd</i>		Manual Open Command	
	<i>CL-Cmd</i>		Close Command	
	<i>C/Bfail</i>		Circuit Breaker failure	
	<i>L/Rdisc</i>		Local/Remote signal Discrepancy	
	<i>Gen.Start</i>		Start Generic	
	<i>Gen.Trip</i>		Trip Generic	
	<i>OscilloTriggerLogic</i>		User Variable for Oscillographic Recording	
	<i>UserVar&lt;0&gt;</i>		User Variable	
	<i>to</i>			
	<i>UserVar&lt;24&gt;</i>		User Variable	
	<i>Vcc</i>		Reserved	
	<i>Gnd</i>		Reserved	
	<i>ResLog</i>		Reset signal logic	
	<i>P1</i>			
<i>to</i>		Push-button		
<i>P6</i>				
<i>0.D1</i>		Digital Input "0.D1"	activated	Digital Inputs
<i>0.D1Not</i>		Digital Input "0.D1"	deactivated	
<i>to</i>				
<i>0.D8</i>		Digital Input "0.D8"	activated	
<i>0.D8Not</i>		Digital Input "0.D8"	deactivated	



### 17.23.4 – Setting "User Trigger Oscillo"

The "User trigger Oscillo" is a result of a logical operation (Or, AND, ecc...), it can be used like other logical output. This operation is possible only via software.

Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
------	-------------	------------------	---------	-------	------------	-------	----------------

#### 17.23.4.1 - Name

Internal name

#### 17.23.4.2 - User descr.

Fixed

#### 17.23.4.3 - Linked functions

Selection functions

#### 17.23.4.4 - OpLogic

Operation Logic = [None, OR, AND, XOR, NOR, NAND, NOT, Ff-SR, Counter, Rise-UP, Fall-Down]

#### 17.23.4.5 - Timer

Time delay (0 ÷ 600)s, step 0.01s

#### 17.23.4.6 - Timer type

<i>Delay</i>	= Add a delay on output activation. The "Timer" is edge triggered on rise edge.
<i>Monostable P</i>	= Activated the output for the time "Timer"
<i>Monostable N</i>	= Disactivated the output for the time "Timer".
<i>Blinking</i>	= The output switches periodically at the frequency defined by "Timer".
<i>Delay-Fall-Down</i>	= <i>Delay-Fall-Down</i>

#### 17.23.4.7 - Extra

Extra Time (0 ÷ 65000)s, step 1s


#### 17.23.4.8 - Logical status

"User Trigger Oscillo" Logical status


*17.24.5 – Example: Setting "Oscillo Trigger Logic"*

Open software program and connect to the relay.

Select "Change Windows" from "Menu" button



Select "User Variable"




Setting for "User Trigger Oscillo" : "1I>/2I>/3I>", "AND", "1", "Monostable", "10".


Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
UserTrigger Oscillo	UserTrigger Oscillo	1I>2I>3I>	AND	1	Monostable P	10	0

*17.25.5.1 – "Linked Functions"*

Select "Linked Functions" related to "User Trigger Oscillo" and press right button on mouse, select "Value change":




Select "1I>, 2I>, 3I>" from "Available" box via push-button "<Add", and press "OK".  
For remove functions, use push-button ">Remove".




17.20.5.2 – "Operation Logic" (Oplogic)

Select "**Oper Logic**" related to "User Trigger Oscillo" and press right button on mouse, select "Value change":




Insert "**AND**" into box and press "OK":




17.20.5.3 – "Timer"

Select "**Timer**" related to "User Trigger Oscillo" and press right button on mouse, select "Value change":




Select "**1**" into box and press "OK":




17.20.5.4 - "Timer type"

Select "**Timer**" related to "User Trigger Oscillo" and press right button on mouse, select "Value change":




Select "**Monostable P**" into box and press "OK":




17.20.5.5 - "Extra"

Select "**Extra**" related to "User Trigger Oscillo" and press right button on mouse,



Select "**10**" into box and press "OK":



**17.24 - Function: CB Mngn (Control C/B)**

This menu allows to configurate the command for C/B operation.

<i>Options</i>	→ <i>L/R</i>	Ignored		[Ignored / Active]
	→ <i>Key</i>	Enable		[Disable / Enable]
	→ <i>Key0</i>	None		[None / P1 / P2 / P3 / P4 / P5 / P6]
	→ <i>KeyC</i>	None		[None / P1 / P2 / P3 / P4 / P5 / P6]
<i>Timers</i>	→ <i>tL/R</i>	0.05	s	(0.05 ÷ 1) step 0.05 s
	→ <i>tC/Bs</i>	0.5	s	(0.05 ÷ 1) step 0.05 s

**17.24.1 - Description of variables**

<i>L/R</i>	: Selection of Local/Remote C/B operation mode Ignored or Active
<i>Key</i>	: <i>Disable</i> = The pushbuttons on Front Panel are disabled; <i>Enable</i> = The pushbuttons on Front Panel are Enable
<i>Key0</i>	: Configure a Key as C/B Open
<i>KeyC</i>	: Configure a Key as C/B Close
<i>tL/R</i>	: Admissible time before detection of the Local/Remote discrepancy alarm.
<i>tC/Bs</i>	: Maximum admissible delay for detection of status signal after C/B operation.


**17.24.2 - Push-Buttons (Programmable only via software)**

It is possible to program up to six buttons on front of the relay, assigning any action / function.

Example: "OPEN C/B" to "P1" and "CLOSE C/B" to "P2".

**17.24.2.1 - "DI Configurations" (Digital Inputs)**

Select "DI configuration":




Assign to:

Type	Functions	
Main C/B CloseSts	0.D1	digital input
Local State	0.D3	digital input
Remote State	0.D4	digital input

ID	Name	Status	Functions
1	Group 1-2	Group-1	
2	ExtR (external reset input)	Not active	
3	Local State	Not active	0.D3,
4	Remote State	Not active	0.D4,
5	C/B Open command	Not active	
6	C/B Close command	Not active	
7	Main C/B CloseSts (Main Circuit Breaker CLOSE position status)	Not active	0.D1,

17.24.2.2 – “User Variables”

Select “User Variable”:




Assign to:

Type	User descr.	Linked Functions
UserVar<0>	UserVar<0>	manOpCmd,Gen.Trip <i>Manual Open Command, Generic Trip</i>
UserVar<1>	UserVar<1>	CL-Cmd <i>Close Command</i>

ID	Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
1	UserTrigger Oscillo	UserTrigger Oscillo		None	0	Delay	0	0
2	UserVar <0>	UserVar <0>	manOpCmd,Gen.Trip	OR	0	Delay	0	0
3	UserVar <1>	UserVar <1>	CL-Cmd	None	0	Delay	0	0

17.24.2.3 – “DO Configuration”

Select “DO Configuration”:




Assign to:

Type	Linked Functions
0.R1	UserVar<0>
0.R2	UserVar<1>

ID	Relay	Linked functions	Logical status	Output config	Function	tON	Relay status
1	0.R1 [Master board, R:1]	UserVar <0>	Off	Normally Denergized	Pulse	0.01	Off
2	0.R2 [Master board, R:2]	UserVar <1>	Off	Normally Denergized	Pulse	0.01	Off


17.24.2.4 – “Function Setting”

Select “Function Setting”:



Assign to “CB Manage”:

Type	Settings
Enable Local/remote	Active
Enable Local Keys	Enable
KeyO	P1
KeyC	P2



17.25 - Function: **ExtResCfg** (External Reset Configuration)

This menu allows to select the edge polarity of the signal on the digital input configured to reset the relay after a trip (see 17.2 input ExtReset).

The reset input will reset all the output relays configured as manual reset (latched), the signalisation of the trip on the display and the indication of the LED are cleared also.

**Options** → **ActOn** RiseEdge [RiseEdge / FallEdge]

17.25.1 - Description of variables

**ActOn** : RiseEdge Active on Rise Edge (Digital Input close).  
FallEdge Active on Fall Edge (Digital Input open).

18. Input – Output (via software)

The firmware can manage up to 8 digital inputs and 8 output relays.

The interfacing software also allows to program the operation of the output relays (Physical Output), and Digital Inputs.

18.1 – Digital Input

<b>0.D1</b>	Programmable (D1)
<b>0.D2</b>	Programmable (D2)
<b>0.D3</b>	Programmable (D3)
<b>0.D4</b>	Programmable (D4)
<b>0.D5</b>	Programmable (D5)
<b>0.D6</b>	Programmable (D6)
<b>0.D7</b>	Programmable (D7)
<b>0.D8</b>	Programmable (D8)

Any digital input is active when the relevant terminals (see wiring diagram) are shorted.

18.2 – "DI" Configuration (via software)

Any of the Digital Inputs can be programmed to control one or more of the following functions.

<b>Bi1I&gt;</b>	Blocking input	First overcurrent element
<b>Bi2I&gt;</b>	Blocking input	Second overcurrent element
<b>Bi3I&gt;</b>	Blocking input	Third overcurrent element
<b>Bi1Io&gt;</b>	Blocking input	First earth fault element
<b>Bi2Io&gt;</b>	Blocking input	Second earth fault element
<b>Bi3Io&gt;</b>	Blocking input	Third earth fault element
<b>Bi1Is&gt;</b>	Blocking input	First negative sequence current element
<b>Bi2Is&gt;</b>	Blocking input	Second negative sequence current element
<b>Group 1-2</b>	Selection of the setting Group 1 or 2.	
<b>Main C/B CloseSts</b>	Main Circuit Breaker CLOSE position status	
<b>ExtR</b>	External Reset input	
<b>Local state</b>	Locate state	
<b>Remote state</b>	Remote state	
<b>C/B open command</b>	Open C/B Command	
<b>C/B close command</b>	Close C/B Command	

18.2.1 – Example

ID	Name	Status	Functions
----	------	--------	-----------

18.2.1.1 – Name

Logical Input name

18.2.1.2 – Status

Logical Input status


18.2.1.3 – Functions

Selection function


18.2.1.4 – Example: Setting "Digital Input"

Open software program and connect to the relay.

Select "Change Windows" from "Menu"



Select "DI configuration"




Setting for "Bi1I>" : "1I>".



ID	Name	Status	Functions
1	Bi1I>	Not active	1I>

18.2.1.5 – "Functions"

Select "Functions" related to "Bi1I>" and press right button on mouse, select "Value change":



From box "Available", select "1I>" and press "Add". Press "OK" for confirmation. (if Password is request, see § Password)



### 18.3 – Physical Outputs

The output relay are fully user programmable and controlled by any protection functions and by any digital inputs.

0.R1	Programmable (R1)
0.R2	Programmable (R2)
0.R3	Programmable (R3)
0.R4	Programmable (R4)
0.R5	Programmable (R5)
0.R6	Programmable (R6)
0.R7	Programmable (R7)
0.R8	Programmable (R8)

*Available in the relay*

### 18.4 - "DO" Configuration

Any Output Relay can be programmed to be controlled (energized) by one or more of the following functions or Digital Inputs:

#### 18.4.1 - Example configuration

ID	Relay	Linked functions	Logical status	Output config	Function	tON	Relay status
1	0.R1 [Master board, R:1]	UserVar <1>	Off	Normally Denergized	Pulse	0,01	Off
2	0.R2 [Master board, R:2]	User Var <2>	Off	Normally Denergized	Pulse	0,01	Off

##### 18.4.1.1 - Relay

Relay internal name

##### 18.4.1.2 - Linked function

It's available only 1 link, select the function for tripping the output relay (for multiple association use "User Variable")

##### 18.4.1.3 - Operation Logic

Not Used

##### 18.4.1.4 - Logical Status

Relay Logical status

##### 18.4.1.5 - Output Configuration

<i>Normally Denergized</i>	The output relay is denergized in normal conditions and gets energized on activation of the controlling Functional Output; reset means denergizing.
<i>Normally Energized</i>	The output relay is energized in normal conditions and gets denergized on activation of the controlling Functional Output; reset means energizing.

##### 18.4.1.6 - tON (Operation Time)

This timer controls the duration of the activation of the output relay.




**tON** :  (0.01-10)s, step 0.01s

##### 18.4.1.7 - Relay Status


Relay – Physical status

18.4.2 - Functions - Operation Mode


- Automatic** : In this mode the output relay is "operated" (energized if "N.D.", dennergized if "N.E.") when the controlling Functional Output is activated and it is reset to the "non operated" condition when the Functional Output gets deactivated but, anyhow, not before the time "tON" has elapsed (minimum duration of the operation time)
- Manual** : In this mode the output relay is "operated" when the controlling Functional Output is activated and remains in the operated condition until a manual reset command is issued by the relay keyboard (local commands menu) or via the serial communication. In this mode the timer "tON" has no effect.
- Impulsive** : In this mode the output relay is "operated" when the controlling Functional Output is activated and it remains in the "operated" condition (energized if "N.D.", dennergized if "N.E.") for the set time "tON" independently from the status of the controlling Functional Output.



Select "Change Windows" from "Menu"



Select "DO Configuration"




18.4.2.1 - Example: Change settings for "0.R1"

Change settings for "0.R1" : "1I>", "Normally Deenergized", "Automatic reset", "0.5".


ID	Relay	Linked functions	Logical status	Output config	Function	tON	Relay status
1	0.R1 [Master board, R:1]	1I>	Off	Normally Deenergized	Pulse	0,5	Off
2	0.R2 [Master board, R:2]		Off	Normally Deenergized	Pulse	0,01	Off

18.4.2.2 - "Linked Functions"

Select "Linked Functions" related to 0.R1 and press right button on mouse, select "Value change":




From box "Available", select "1I>" and press "Add".  
Press "OK" for confirmation. (if Password is request, see § Password)




18.4.2.3 - "Output Config"

Select "Output Config" related to "0.R1" and press right button on mouse, select "Value change":




Select "Normally Deenergized" from combo box and press "OK"  
(if Password is request, see § Password)




18.4.2.4 - "Function"

Select "**Function**" related to "0.R1" and press right button on mouse, select "Value change":




Select "**Manual reset**" from combo box and press "OK"  
(if Password is request, see § Password)




18.4.2.5 - "tON"

Select "**tON**" related to "0.R1" and press right button on mouse, select "Value change":



Set "**0.5**" and press "OK"  
(if Password is request, see § Password)



19. InfoStatus

In this menu is showed the status of relay




**LocR** : Local and Remote Status  
*Disable*  
*Local*  
*Remote*  
*Discrepancy Status*


## 20. Date and Time


In this menu it is possible to configure the Date and Time


<b>Date:</b>	20YY / MM / DD	(2000/01/01 ÷ 2099/12/31) YY = Year / MM = Month / DD = Day
<b>Time:</b>	HH : MM : 00	HH = hour / MM = Minutes / 00
<b>DofW:</b>	Day	Es: Wednesday


- 1**



  - Press "**Menu**" for access to the main menu with icons.
- 2**


  - Select icon "**TimeDate**" by pushbuttons "**Increase**" or "**Decrease**".
  - Press "**Select**".
- 3**


  - Press "**Modify**".
- 4**


  - The last two figures of the Year will appear in bold character; by pushbuttons "**Increase**" or "**Decrease**" set the new figures.
  - Press "**Next**" to go to the next setting.
- 5**


  - As above for changing the "Month"
  - Press "**Next**" to go to the next setting.
- 6**


  - As above for changing the "Day"
  - Press "**Next**" to go to the next setting.

- 7**
- | TimeDate |            |
|----------|------------|
| Date :   | 2016/06/23 |
| Time :   | HH:03:58   |
| DofW :   | Thursday   |
| Prev.    | Next       |
- As above for changing the "Hours"
  - Press "**Next**" to go to the next setting.
- 8**
- | TimeDate |            |
|----------|------------|
| Date :   | 2016/06/23 |
| Time :   | 09:MM:58   |
| DofW :   | Thursday   |
| Prev.    | Next       |
- As above for changing the "Minutes"
  - Press "**Next**" to go to the next setting.
- 9**
- | TimeDate |            |
|----------|------------|
| Date :   | 2016/06/23 |
| Time :   | 09:04:00   |
| DofW :   | Thursday   |
| Prev.    | Next       |
- The **Day of the Week** is calculated and displayed automatically.
  - Press "**Exit**" to go back to the main menu.
  - Press "**Modify**" to go back to the step "3"



Press the button "**Next**" to go back to the previous display.

### 20.1- Clock synchronization

The internal clock has 1ms resolution and a stability of  $\pm 35\text{ppm}$  in the operational temperature range.

It can be synchronized with an external time reference in the following ways:

- Using the standard "Time Synchronization" procedure of the "IEC870-5-103" protocol.
- Using the software or from the DCS with the Modbus RTU protocol.

**21. Healthy (Diagnostic Information)**

The relay operates a continuous checking of the vital functionalities and in case an internal failure is detected, the I.R.F. function (see § I.R.F.) is activated and the Power/IRF led is set to flashing.

<b>Device</b>	→	<i>No Fail</i>	→	No Fail
		<i>Fail</i>	→	Fail present
		<i>MinorFail</i>	→	Minor Fail
		<i>HistoricalFail</i>	→	Cleared Fail
		<i>IAU FW notC</i>	→	Firmware MPUs not compatible

<b>Boards</b>	→	<i>Int.Ram</i>	→	Internal RAM fault
		<i>SCI 1</i>	→	Serial comm. Controller 1
		<i>SCI 2</i>	→	Serial comm. Controller 2
		<i>SDRAM</i>	→	SDRAM fault
		<i>Keys</i>	→	Keyboard failure
		<i>TK stop/fail</i>	→	Time Keeper to sync or stopped/failure
		<i>E2pCorrupt</i>	→	E2P Corrupt
		<i>SRAM</i>	→	SRAM Corrupt
		<i>Code Corrupt</i>	→	Code Corrupt
		<i>Data Corrupt</i>	→	Data Corrupt
		<i>SPI</i>	→	Serial peripheral interface
		<i>IIC</i>	→	I2C bus failure

If an internal self-clearing (transient) fault is detected, it is recorded into an historical file without any other action.

**22. Dev.Info (Relay Version)**


In this menu it is possible to read the information relevant to relay unit.

<i>SW Version</i>	<i>IPU-R</i>	→	####.##.##.##	Firmware version
<i>Protect.Model</i>		→	xxxxxx	Protection Type
<i>Serial Number</i>		→	###/##/##/####	Relay Serial Number
<i>User Tag</i>		→	xxxxxxx	Relay identification label. This information can only be modified by the interface program software and allows the user to give to the relay any suitable denomination.
<i>Build</i>		→	#####	Build identification label.
<i>Line</i>		→	#####	Line identification label.


**23. Maintenance**

No maintenance is required. In case of malfunctioning please contact Service or the local Authorized Dealer mentioning the relay's Serial No reported in the label on relays enclosure.

24. Wiring Diagram



25. Overall Dimensions





## 26. Electrical Characteristics

### Approval: CE

Reference Standards IEC 60255 - CE Directive - EN/IEC61000 - IEEE C37

Dielectric test voltage	IEC 60255-5	2kV, 50/60Hz, 1 min.
Impulse test voltage	IEC 60255-5	5kV (c.m.), 2kV (d.m.) - 1,2/50µs
Insulation resistance	> 100MΩ	

### Environmental Std. Ref. (IEC 60068)

Operation ambient temperature	-10°C / +55°C
Storage temperature	-25°C / +70°C
Environmental testing	(Cold) IEC60068-2-1
	(Dry heat) IEC60068-2-2
	(Change of temperature) IEC60068-2-14
	(Damp heat, steady state) IEC60068-2-78 RH 93% Without Condensing AT 40°C

### CE EMC Compatibility (EN61000-6-2 - EN61000-6-4 - EN50263)

Electromagnetic emission	EN55011	industrial environment
Radiated electromagnetic field immunity test	IEC61000-4-3	level 3 80-200MHz 10V/m
	ENV50204	900MHz/200Hz 10V/m
Conducted disturbances immunity test	IEC61000-4-6	level 3 0.15-80MHz 10V
Electrostatic discharge test	IEC61000-4-2	level 3 6kV contact / 8kV air
Power frequency magnetic test	IEC61000-4-8	1000A/m 50/60Hz
Pulse magnetic field	IEC61000-4-9	1000A/m, 8/20µs
Damped oscillatory magnetic field	IEC61000-4-10	100A/m, 0.1-1MHz
Immunity to conducted common mode disturbance 0Hz-150KHz	IEC61000-4-16	level 4
Electrical fast transient/burst	IEC61000-4-4	level 3 2kV, 5kHz
HF disturbance test with damped oscillatory wave (1MHz burst test)	IEC60255-22-1	class 3 400pps, 2,5kV (m.c.), 1kV (d.m.)
Oscillatory waves (Ring waves)	IEC61000-4-12	level 4 4kV(c.m.), 2kV(d.m.)
Surge immunity test	IEC61000-4-5	level 4 2kV(c.m.), 1kV(d.m.)
Voltage interruptions	IEC60255-4-11	
Resistance to vibration and shocks	IEC60255-21-1 - IEC60255-21-2	10-500Hz 1g

### Characteristics

Accuracy at reference value of influencing factors	1% In for measure 2% + to (to=20÷30ms @ 2xIs) for times
Rated Current	In = 1 or 5A - On = 1 or 5A
Current Overload	100 In for 1 sec; 4 In continuous
Burden on current inputs	Phase : 0.01VA at In = 1A; 0.2VA at In = 5A Neutral : 0.01VA at In = 1A ; 0.2VA at In = 5A
Average power supply consumption	< 10 VA
Output relays	rating 5 A; Vn = 380 V A.C. resistive switching = 1100W (380V max) make = 30 A (peak) 0,5 sec. break = 0.3 A, 110 Vcc, L/R = 40 ms (100.000 op.)

### Communication Parameter

Rear serial port (Terminal Blocks)	RS485 - 9600 to 38400 bps - 8,n,1 - Modbus RTU - IEC60870-5-103
Front serial port (USB)	RS232(virtual) - 9600 to 57600 bps - 8,n,1 - Modbus RTU

This publication may be subject to alteration without prior notice. Therefore, a printed copy of this document may not be the latest revision. Please contact your local representative for the latest update. The trademarks MS Microelettrica Scientifica, Knorr and Knorr-Bremse as well as the figurative mark "K" are registered. Copyright © Knorr-Bremse AG and Microelettrica Scientifica SpA - all rights reserved, including industrial property rights application. Knorr-Bremse AG and Microelettrica Scientifica SpA retain any power of disposal, such as for copying and transferring.



### Microelettrica Scientifica S.p.A.

20090 Buccinasco (MI) · Via Lucania 2 · Italy · Tel.: +39 02 575731  
E-Mail: info@microelettrica.com · www.microelettrica.com