

# MICROPROCESSOR OVERCURRENT and EARTH FAULT RELAY

TYPE

# MC30

## OPERATION MANUAL



1. General Utilization and Commissioning Directions	4
1.1 - Storage and Transportation	4
1.2 - Installation	4
1.3 - Electrical Connection	4
1.4 - Measuring Inputs and Power Supply	4
1.5 - Outputs Loading	4
1.6 - Protection Earthing	4
1.7 - Setting and Calibration	4
1.8 - Safety Protection	4
1.9 - Handling	4
1.10 - Maintenance	5
1.11 - Waste Disposal of Electrical & Electronic Equipment	5
1.12 - Fault detection and repair	5
2. General Characteristics	6
2.1 - Power Supply	6
2.2 - Operation and Algorithms	7
2.2.1 - Reference Input Values	7
2.2.2 - Input quantities	7
2.2.3 - Time Current Curves IEC (TU1029 Rev.0)	9
2.2.4 - Time Current Curves IEEE (TU1028 Rev.0)	10
3. Functions and Settings (Function)	11
3.1 - T> (F49) - Thermal Image protection level	11
3.1.1 - Thermal Image Curves (TU0445 Rev.0)	12
3.2 - I> (1F51) - First overcurrent protection level	13
3.3 - I>> (2F51) - Second overcurrent protection level	13
3.4 - IH (3F51) - Third overcurrent protection level	14
3.4.2 - Automatic doubling or Overcurrent thresholds on current inrush	14
3.5 - Io> (1F51N) - First Earth Fault protection level	15
3.6 - Io>> (2F51N) - Second Earth Fault protection level	16
3.7 - IoH (3F51N) - Third Earth Fault protection level	16
3.8 - BF (F51BF) - Breaker Failure	17
3.9 - I.R.F. - Internal Relay Failure	17
3.10 - Osc - Oscillographic Recording	18
3.11 - Comm - Communication Parameters	19
3.12 - LCD - Display and Buzzer operation	19
4. Logic Blocking of Functions	20
4.1 - Blocking Outputs	20
4.2 - Blocking Inputs	20
5. Output Relays	20
5.1 - Output Relay	20
5.2 - "OutCfg" Outputs Configuration - via MCom2 software	20
5.2.1 - "Example"	20
5.2.2 - "Relay"	20
5.2.3 - "Output Configuration"	20
5.2.4 - "Function"	21
5.2.5 - "Operation Logic"	21
5.2.6 - "Output Configuration"	22
5.2.7 - "Timer - Operation Time"	22
5.3 - Example: Change settings for "0.R1"	23
5.3.1 - "Output Config"	23
5.3.2 - "Functions"	23
5.3.3 - "OpLogic"	24
5.3.4 - "Output config"	24
5.3.5 - "Timer"	25
6. Digital Inputs	26
6.1 - Digital Input on Main Module (only via MCom Software)	26
6.2 - Functions available	26
7. Self-diagnostic	26
8. Relay Management	27
9. Signalizations	28
10. Keyboard Buttons	28
11. Serial Communication Port	29
11.1 - Main RS485 Serial Communication Port	29
11.2 - Communication Port on Front Face Panel	30
12. Menu and Variables	31
12.1 - Real Time Measurements	31
12.2 - Measure (Instantaneous Measurements)	31
12.3 - Counter (Operation Counters)	31
12.4 - LastTrip (Event Recording)	32
12.5 - R/W Set (Programming / Reading the Relay Settings)	33
12.5.1 - CommAdd (Communication Address)	33
12.5.2 - Time/Date (Time/Date)	33



12.5.3 - RatedVal (Rated Input Values)	33
12.5.4 - Function (Functions)	34
12.6 - Commands	35
12.7 - Info&Ver (Firmware - Info&Version)	35
13. Keyboard Operational Diagram	36
14. Password	37
14.1 - MS-Com Password	37
15. Maintenance	37
16. Power Frequency Insulation Test	37
17. Connection Diagram	38
18. Overall Dimensions	38
19. Direction for Pcb's Draw-Out and Plug-In	39
19.1 - Draw-Out	39
19.2 - Plug-In	39
20. Electrical Characteristics	40

## 1. General Utilization and Commissioning Directions

---

Always make reference to the specific description of the product and to the Manufacturer's instruction. Carefully observe the following warnings.

### 1.1 - Storage and Transportation

---

Must comply with the environmental conditions stated on the product's instruction or by the applicable IEC standards.

### 1.2 - Installation

---

Must be properly made and in compliance with the operational ambient conditions stated by the Manufacturer.

### 1.3 - Electrical Connection

---

Must be made strictly according to the wiring diagram supplied with the Product, to its electrical characteristics and in compliance with the applicable standards particularly with reference to human safety.

### 1.4 - Measuring Inputs and Power Supply

---

Carefully check that the value of input quantities and power supply voltage are proper and within the permissible variation limits.

### 1.5 - Outputs Loading

---

Must be compatible with their declared performance.

### 1.6 - Protection Earthing

---

When earthing is required, carefully check its effectiveness.

### 1.7 - Setting and Calibration

---

Carefully check the proper setting of the different functions according to the configuration of the protected system, the safety regulations and the co-ordination with other equipment.

### 1.8 - Safety Protection

---

Carefully check that all safety means are correctly mounted, apply proper seals where required and periodically check their integrity.

### 1.9 - Handling

---

Notwithstanding the highest practicable protection means used in designing M.S. electronic circuits, the electronic components and semiconductor devices mounted on the modules can be seriously damaged by electrostatic voltage discharge which can be experienced when handling the modules.

The damage caused by electrostatic discharge may not be immediately apparent, but the design reliability and the long life of the product will have been reduced. The electronic circuits reduced by M.S. are completely safe from electrostatic discharge (8 kV IEC 255.22.2) when housed in their case; withdrawing the modules without proper cautions expose them to the risk of damage.

- a. Before removing a module, ensure that you are at the same electrostatic potential as the equipment by touching the case.
- b. Handle the module by its front-plate, frame, or edges of the printed circuit board. Avoid touching the electronic components, printed circuit tracks or connectors.
- c. Do not pass the module to any person without first ensuring that you are both at the same electrostatic potential. Shaking hands achieves equipotential.
- d. Place the module on an antistatic surface, or on a conducting surface which is at the same potential as yourself.
- e. Store or transport the module in a conductive bag.

More information on safe working procedures for all electronic equipment can be found in BS5783 and IEC 147-OF.



### 1.10 - Maintenance

Make reference to the instruction manual of the Manufacturer; maintenance must be carried-out by specially trained people and in strict conformity with the safety regulations.

### 1.11 - Waste Disposal of Electrical & Electronic Equipment

(Applicable throughout the European Union and other European countries with separate collection program). This product should not be treated as household waste when you wish dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequence to the environment and human health, which could otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resource.

### 1.12 - Fault detection and repair

Internal calibrations and components should not be altered or replaced.  
For repair, please ask the Manufacturer or its authorized Dealers.

Misapplication of the above warnings and instruction relieves the Manufacturer of any liability.

## 2. General Characteristics

The MC is a very innovative and versatile line of Protective Relays which takes advantage of the long and successful experience coming from the M-Line.

The main features of the MC-Line relays are:

Compact draw-out execution for Flush Mounting or for assembly in 19" 3U chassis for 19" Rack systems.

User friendly front face with 2x8 characters LCD Display, four signal Leds, four keys for complete local management and 9-pin socket for local RS232 serial communication.

Four user programmable Output Relays. On request one of the Output Relays can be replaced by a Can Bus port for control of additional I/O modules.

Three optoisolated, self-powered Digital Inputs.

RS485 communication port (independent from the RS232 port on front panel)

Totally draw-out execution with automatic C.T. shorting device.

Input currents are supplied to 3 current transformers: measuring phase currents.

An additional internal CT directly measures the residual (Zero Sequence) current of the three inputs.


Current inputs can be 1 or 5A: selection between 1A or 5A is made by movable jumpers provided on the Relay card. (see Fig 1)

### **The Measuring Ranges of the different inputs respectively are:**

Phase Currents	: (0.1-40) In
Residual Current	: (0.01-10) In

Make electric connection in conformity with the diagram reported on relay's enclosure.

Check that input currents are same as reported on the diagram and on the test certificate.



### 2.1 - Power Supply

The auxiliary power is supplied by a built-in module fully isolated and self-protected.

The relay can be fitted with two different types of **power supply**:

Type 1	24V(-20%) / 110V(+15%) a.c.	24V(-20%) / 125V(+20%) d.c.
Type 2	80V(-20%) / 220V(+15%) a.c.	90V(-20%) / 250V(+20%) d.c.

Before energizing the unit check that supply voltage is within the allowed limits.

## 2.2 - Operation and Algorithms

### 2.2.1 - Reference Input Values

	Display		Description	Setting Range	Step	Unit
I1	100	A	Rated Primary current of phase C.T.	1 - 9999	1	A
I2	5	A	Rated Secondary current of phase C.T.	1 - 5	1/5	A
In	100	A	Reference primary current of the relay	1 - 9999	1	A
Freq	50	Hz	System rated frequency	50 - 60	10	Hz
TW	30	min	Warming-up time constant for Thermal Image	1 - 60	1	min.
Ib	105	%In	Maximum admissible continuous overload for Thermal Image	50 - 130	1	%In

### 2.2.2 - Input quantities

#### 2.2.2.1 - Mains Frequency (Freq)

The relay can operate either in 50Hz or 60Hz systems.  
The rated Mains Frequency "Freq" must be set accordingly.

#### 2.2.2.2 - Phase Current inputs (I1)

The relay directly displays the r.m.s. value of the Phase Currents "**IA**", "**IB**", "**IC**" flowing in the Primary of the input Current Transformers and refers all its measurements to that value.  
To make the relay properly working with any C.T., when programming the relay settings, input the value "I1" of the primary current of the phase C.Ts

The measure is not displayed below : < 5% In

#### 2.2.2.3 - Earth Fault Current Input (Ion)

Same as for the Phase Currents, the relay directly displays the r.m.s. value of the Zero Sequence Residual Current flowing at the Primary of the Current Transformers.

The measure is not displayed below : < 1% On

#### 2.2.2.4 - Algorithm of the time current curves

The Time Current Curves are generally calculated with the following equation :

$$(1) \quad t(I) = \left[ \frac{A}{\left( \frac{I}{I_s} \right)^a - 1} + B \right] \bullet K \bullet T_s + t_r$$

where:

$t(I)$  = Actual trip time delay when the input current equals "I"

$I$  = Maximum of the three input currents.

$I_s$  = Set minimum pick-up level

$$K = \left( \frac{A}{10^a - 1} \right)^{-1}$$

$T_s$  = Set time delay:  $t(I) = T_s$  when  $\frac{I}{I_s} = 10$

$t_r$  = Operation time of the output relay on pick-up (7ms).


The parameters "A" and "a" have different values for the different Time Current Curves.

Curve Name	Curve Identifier	A	B	a
IEC A Inverse	A	0.14	0	0.02
IEC B Very Inverse	B	13.5	0	1
IEC C Extremely Inverse	C	80	0	2
IEEE Moderate Inverse	MI	0.0104	0.0226	0.02
IEEE Short Inverse	SI	0.00342	0.00262	0.02
IEEE Very Inverse	VI	3.88	0.0963	2
IEEE Inverse	I	5.95	0.18	2
IEEE Extremely Inverse	EI	5.67	0.0352	2

**The maximum measuring current is "40xIn" for phase elements and "10xOn" for the neutral element.**




### 2.2.3 - Time Current Curves IEC (TU1029 Rev.0)



Curve Type	A	B	K	a
IEC A	0.14	0	0.336632	0.02
IEC B	13.5	0	0.666667	1
IEC C	80	0	1.2375	2

Max. "I" Phase =  $40 \times I_n$   
 Max. "I" Neutral =  $10 \times I_n$

### 2.2.4 - Time Current Curves IEEE (TU1028 Rev.0)



Curve Type	A	B	K	a
MI= IEEE Moderate Inv.	0.0104	0.0226	4.110608	0.02
SI= IEEE Short Inv.	0.00342	0.00262	13.30009	0.02
VI= IEEE Very Inv.	3.88	0.0963	7.380514	2
I= IEEE Inverse	5.95	0.18	4.164914	2
EI= IEEE Extremely Inv.	5.67	0.0352	10.814	2

Max. "I" Phase =  $40 \times I_n$   
 Max. "I" Neutral =  $10 \times I_n$

### 3. Functions and Settings (Function)

#### 3.1 - T> (F49) - Thermal Image protection level

<i>FuncEnab</i>	→	Enable	[Disable / Enable]			
<i>Options</i>	→	No Param	No Parameters			
<i>TripLev</i>	→	<b>Tal</b>	50	%Tb	(50 ÷ 110)	step 1 %Tb
	→	<b>Tst</b>	100	%Tb	(10 ÷ 100)	step 1 %Tb
<i>Timers</i>	→	No Param	No Parameters			

#### Description of variables

<b>FuncEnab</b>	:	If disable the function is disactivated.
<b>Tal</b>	:	Thermal prealarm temperature.
<b>Tst</b>	:	Reset level.

<i>Trip when</i>	:	The temperature exceeded for time "Tal".
<i>When the function is tripped</i>	:	<i>Signalization</i> = Led "Trip" is illuminated
	:	<i>Last Trip</i> = Is recorded
<i>Led reset when</i>	:	Return in normal condition

Warming-up is computed proportionally to the square of the largest phase current "I".

- Allowed overloading time (See Curve)

The trip time delay "t" of the thermal element, depends on the warming-up time constant "tw", on the previous thermal status (Ip/In)<sup>2</sup>, on the admissible continuous overload (Ib) and, of course, on the actual load (I)


$$t = tw \cdot \ell_n \left[ \frac{(I/In)^2 - (Ip/In)^2}{(I/In)^2 - (Ib/In)^2} \right] \quad \text{where :}$$

<b>tw</b>	=	Warming-up time constant	(1-60) min.
<b>I</b>	=	Largest of the three phase currents	
<b>Ip</b>	=	Preheating current: Steady-State Current corresponding to the thermal status existing at the moment when the current is increased to the overload value "I"	
<b>Ib</b>	=	Continuously admissible current	(50-130) %In, step 1%In
<b>In</b>	=	Rated primary current of phase C.Ts	
<b>ℓ<sub>n</sub></b>	=	Natural logarithm	

Reset takes place when the simulated temperature drops below the programming level [Tst].

An alarm signal is issued when the computed warming exceeds the set percentage "Tal" of the Full Load temperature "Tb".

### 3.1.1 - Thermal Image Curves (TU0445 Rev.0)



### 3.2 - I> (1F51) - First overcurrent protection level

<b>FuncEnab</b>	→	Enable		[Disable / Enable]
<b>Options</b>	→	<b>TCC</b>	D	[D / A / B / C / MI / VI / I / EI / SI]
	→	<b>BI</b>	Disable	[Disable / Enable]
	→	<b>Trg</b>	Enable	[Disable / Enable]
<b>TripLev</b>	→	<b>I&gt;</b>	0.1	In (0.1 ÷ 4) step 0.01 In
<b>Timers</b>	→	<b>tI&gt;</b>	0.05	s (0.05 ÷ 60) step 0.01 s

#### Description of variables

<b>FuncEnab</b>	:	If disable the function is deactivated
<b>TCC</b>	:	Time current curves
		<i>D</i> = Independent Definite Time
		<i>A</i> = IEC A Inverse
		<i>B</i> = IEC B Very Inverse
		<i>C</i> = IEC C Extremely Inverse
		<i>MI</i> = IEEE Moderate Inverse Curve
		<i>VI</i> = IEEE Very Inverse Curve
		<i>I</i> = IEEE Inverse Curve
		<i>EI</i> = IEEE Extremely Inverse Curve
		<i>SI</i> = IEEE Short Inverse Curve
<b>BI</b>	:	Operation controlled by Blocking Digital Input
<b>Trg</b>	:	Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b>I&gt;</b>	:	Minimum phase current pick-up level (limited to 40 times In)
<b>tI&gt;</b>	:	Trip time delay
<b>Trip when</b>	:	The current trip level is exceeded for time "tI>".
<b>When the function is tripped</b>	:	<i>Signalization</i> = Led "Trip" is illuminated
		<i>Last Trip</i> = Is recorded
<b>Function reset when</b>	:	The current drop below 95% I>.
<b>Led reset when</b>	:	push-button is pressed

### 3.3 - I>> (2F51) - Second overcurrent protection level

<b>FuncEnab</b>	→	Enable		[Disable / Enable]
<b>Options</b>	→	<b>BI</b>	Disable	[Disable / Enable]
	→	<b>2xI</b>	Disable	[Disable / Enable]
	→	<b>Trg</b>	Enable	[Disable / Enable]
<b>TripLev</b>	→	<b>I&gt;&gt;</b>	0.5	In (0.50 ÷ 40) step 0.01 In
<b>Timers</b>	→	<b>tI&gt;&gt;</b>	0.05	s (0.05 ÷ 60) step 0.01 s
	→	<b>t2xI</b>	0.02	s (0.02 ÷ 9.99) step 0.01 s

#### Description of variables

<b>FuncEnab</b>	:	If disable the function is deactivated
<b>BI</b>	:	Operation controlled by Blocking Digital Input
<b>2xI</b>	:	Automatic threshold doubling on inrush
<b>Trg</b>	:	Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b>I&gt;&gt;</b>	:	Minimum phase current pick-up level (limited to 40 times In)
<b>tI&gt;&gt;</b>	:	Trip time delay
<b>t2xI</b>	:	Trip time delay
<b>Trip when</b>	:	The current trip level is exceeded for time "tI>>".
<b>When the function is tripped</b>	:	<i>Signalization</i> = Led "Trip" is illuminated
		<i>Last Trip</i> = Is recorded
<b>Function reset when</b>	:	The current drop below 95% I>>.
<b>Led reset when</b>	:	push-button is pressed

### 3.4 - IH (3F51) - Third overcurrent protection level

FuncEnab	→	Enable	[Disable / Enable]
Options	→	<b>BI</b> Disable	[Disable / Enable]
	→	<b>2xI</b> Enable	[Disable / Enable]
	→	<b>Trg</b> Enable	[Disable / Enable]
TripLev	→	<b>IH</b> 0.5	In (0.5 ÷ 40) step 0.01 In
Timers	→	<b>tIH</b> 0.05	s (0.05 ÷ 60) step 0.01 s
	→	<b>t2xI</b> 0.02	s (0.02 ÷ 9.99) step 0.01 s

#### Description of variables

<b>FuncEnab</b>	: If disable the function is deactivated
<b>BI</b>	: Operation controlled by Blocking Digital Input
<b>2xI</b>	: Automatic threshold doubling on inrush
<b>Trg</b>	: Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b>IH</b>	: Minimum phase current pick-up level (limited to 40 times In)
<b>t2xI</b>	: Trip time delay
<b>tIH</b>	: Trip time delay

<i>Trip when</i>	: The current trip level is exceeded for time "tIH".
<i>When the function is tripped</i>	: <i>Signalization</i> = Led "Trip" is illuminated
	: <i>Last Trip</i> = Is recorded
<i>Function reset when</i>	: The current drop below 95% IH.
<i>Led reset when</i>	: push-button is pressed

#### 3.4.2 – Automatic doubling or Overcurrent thresholds on current inrush

For some of the phase Overcurrent functions it is possible to have the set trip level [Is] automatically doubled when strong inrush current is detected.

If at circuit Breaker switch-on (i.e. when the input current rises from zero to a minimum measurable value) the current increases from 0 to 1.5 times the rated value [In] in less than 60ms, the set minimum pick-up level [Is] is dynamically doubled ([Is]→[2Is]) and keeps this value until the input current drops below 1.25xIn or the set time [t2xI] has elapsed.

This functionality is very useful to avoid spurious tripping of the instantaneous or short-time delayed Overcurrent elements that could be experienced at switch-on of reactive loads like Transformer or Capacitors.

### 3.5 - $I_{o>}$ (1F51N) - First Earth Fault protection level

FuncEnab	→	Enable	[Disable / Enable]
Options	→	<b>TCC</b> D	[D / A / B / C / I / VI / EI / MI / SI]
	→	<b>BI</b> Disable	[Disable / Enable]
	→	<b>Trg</b> Enable	[Disable / Enable]
TripLev	→	<b><math>I_{o&gt;}</math></b> 0.01	Ion (0.01 ÷ 4) step 0.01 Ion
Timers	→	<b><math>tI_{o&gt;}</math></b> 0.05	s (0.05 ÷ 60) step 0.01 s

#### Description of variables

<b>FuncEnab</b>	:	If disable the function is deactivated
<b>TCC</b>	:	Time current curves
		<i>D</i> = Independent Definite Time
		<i>A</i> = IEC A Inverse
		<i>B</i> = IEC B Very Inverse
		<i>C</i> = IEC C Extremely Inverse
		<i>MI</i> = IEEE Moderate Inverse Curve
		<i>VI</i> = IEEE Very Inverse Curve
		<i>I</i> = IEEE Inverse Curve
		<i>EI</i> = IEEE Extremely Inverse Curve
		<i>SI</i> = IEEE Short Inverse Curve
<b>BI</b>	:	Operation controlled by Blocking Digital Input
<b>Trg</b>	:	Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b><math>I_{o&gt;}</math></b>	:	Minimum Zero Sequence Residual Current Pick-up level
<b><math>tI_{o&gt;}</math></b>	:	Trip time delay
<i>Trip when</i>	:	The current trip level is exceeded for time " $tI_{o>}$ ".
<i>When the function is tripped</i>	:	<i>Signalization</i> = Led "Trip" is illuminated
		<i>Last Trip</i> = Is recorded
<i>Function reset when</i>	:	The current drop below 95% $I_{o>}$ .
<i>Led reset when</i>	:	push-button is pressed

### 3.6 - Io>> (2F51N) - Second Earth Fault protection level

FuncEnab	→	Enable	[Disable / Enable]					
Options	→	<b>BI</b>	Disable	[Disable / Enable]				
	→	<b>Trg</b>	Enable	[Disable / Enable]				
TripLev	→	<b>Io&gt;&gt;</b>	0.01	Ion	(0.01 ÷ 9.99)	step	0.01	Ion
Timers	→	<b>tIo&gt;&gt;</b>	0.05	s	(0.05 ÷ 60)	step	0.01	s

#### Description of variables

<b>FuncEnab</b>	: If disable the function is deactivated
<b>BI</b>	: Operation controlled by Blocking Digital Input
<b>Trg</b>	: Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b>Io&gt;&gt;</b>	: Minimum Zero Sequence Residual Current Pick-up level
<b>tIo&gt;&gt;</b>	: Trip time delay

<i>Trip when</i>	: The current trip level is exceeded for time "tIo>>"
<i>When the function is tripped</i>	: <i>Signalization</i> = Led "Trip" is illuminated
	: <i>Last Trip</i> = Is recorded
<i>Function reset when</i>	: The current drop below 95% Io>>.
<i>Led reset when</i>	: push-button is pressed

### 3.7 - IoH (3F51N) - Third Earth Fault protection level

FuncEnab	→	Enable	[Disable / Enable]					
Options	→	<b>BI</b>	Disable	[Disable / Enable]				
	→	<b>Trg</b>	Enable	[Disable / Enable]				
TripLev	→	<b>IoH</b>	0.01	Ion	(0.01 ÷ 9.99)	step	0.01	Ion
Timers	→	<b>tIoH</b>	0.05	s	(0.05 ÷ 60)	step	0.01	s

#### Description of variables

<b>FuncEnab</b>	: If disable the function is deactivated
<b>BI</b>	: Operation controlled by Blocking Digital Input
<b>Trg</b>	: Function operation triggers the oscillographic wave form capture (see § Oscillographic Recording)
<b>IoH</b>	: Minimum Zero Sequence Residual Current Pick-up level
<b>tIoH</b>	: Trip time delay

<i>Trip when</i>	: The current trip level is exceeded for time "tIoH".
<i>When the function is tripped</i>	: <i>Signalization</i> = Led "Trip" is illuminated
	: <i>Last Trip</i> = Is recorded
<i>Function reset when</i>	: The current drop below 95% IoH.
<i>Led reset when</i>	: Push-button is pressed



### 3.8 - BF (F51BF) - Breaker Failure

FuncEnab	→	Enable	[Disable / Enable]
Options	→	TrR	Relay1 – Relay2 – Relay3 – Relay4
TripLev	→	No Param	No Parameters
Timers	→	tBF	0.2 s (0.05 ÷ 0.75) step 0.01 s

#### Description of variables

FuncEnab	:	If disable the function is deactivated
TrR	:	Output relay programmed for trip command to the Circuit Breaker
tBF	:	Trip time delay

**Operation:** If after the time "tBF" from pick-up of the programmed relay "TrR" the current measured still exceeds 5%In, the output relay associated to the "BF" function is operated (relay another than TrR).

### 3.9 - I.R.F. - Internal Relay Failure

FuncEnab	→	No Param	No Parameters
Options	→	Opl	[NoTrip / Trip]
TripLev	→	No Param	No Parameters
Timers	→	No Param	No Parameters

#### Description of variables

Opl	:	The variable "Opl" can be programmed to trip the output relays same as the other protection functions (Opl = TRIP), or to only operate the "IRF" signal led without tripping the output relays (Opl = NoTRIP).
Trip when	:	an internal fault in the relay is detected (see Diagnostics)
When the function is tripped	:	Signalization = Led "PWR/I.R.F." blink
	:	Last Trip = Is recorded
Function reset when	:	it returns to normal operation
Led reset when	:	Push-button is pressed



## 3.10 - Osc - Oscillographic Recording

<i>FuncEnab</i>	→	Enable	[Disable / Enable]							
<i>Options</i>	→	<b>Trg</b>	Trip	[Disable / Start / Trip / Ext.Inp.]						
<i>TripLev</i>	→	No Param	No Parameters							
<i>Timers</i>	→	<b>tPre</b>	0.3	s	(0.1 ÷ 0.5)	step	0.1	s		
	→	<b>tPost</b>	0.3	s	(0.1 ÷ 1.5)	step	0.1	s		

## Description of variables

<i>FuncEnab</i>	:	If disable the function is disactivated		
<i>Trg</i>	:	<i>Disab</i>	=	Function Disable (no recording)
		<i>Start.</i>	=	Trigger on time start of protection functions
		<i>Trip</i>	=	Trigger on trip (time delay end) of protection functions
		<i>Ext.Inp.</i>	=	Trigger from the Digital Input D3
<i>tPre</i>	:	Recording time before Trigger		
<i>tPost</i>	:	Recording time after Trigger		

When the option "Start" or "Trip" is selected:

The oscillographic recording is started respectively by the "Time Start" or by the "Time End" of any of the functions that have been programmed to Trigger the Wave Form Capture (I>, I>>, IH, Io>, Io>>, IoH).

The "Osc" Function includes the wave Form Capture of the input quantities (IA, IB, IC, Io) and can totally store a record of 3 seconds.

The number of events recorded depends on the duration of each individual recording (tPre + tPost).

In any case the number of events stored cannot exceed ten (10 x 0.3 sec).

Any new event beyond the 3 sec capacity of the memory, cancel and overwrites the former records (FIFO Memory).



## 3.11 - Comm – Communication Parameters

FuncEnab	→	No Param	No Parameters
Options	→	<b>LBd</b>	9600
	→	<b>RBd</b>	9600
	→	<b>Mod</b>	8,n,1
	→	<b>RPr</b>	Modbus
TripLev	→	No Param	No Parameters
Timers	→	No Param	No Parameters

## Description of variables

<b>LBd</b>	:	Local Baud Rate (Front panel RS232 communication speed)
<b>RBd</b>	:	Remote Baud Rate (Rear panel terminal blocks RS485 communication speed)
<b>Mod</b>	:	Remote mode (communication parameters) <b>Note:</b> Any change of this setting becomes valid at the next power on
<b>RPr</b>	:	Remote Protocol

## 3.12 - LCD – Display and Buzzer operation

FuncEnab	→	No Param	No Parameters
Options	→	<b>Key</b>	BeepON
	→	<b>BkL</b>	Auto
	→	<b>AnF</b>	View
TripLev	→	No Param	No Parameters
Timers	→	No Param	No Parameters

## Description of variables

<b>Key</b>	:	Buzzer "Beep" on operation of Keyboard buttons.
<b>BkL</b>	:	LCD Backlight continuously "ON" or switched-on Automatically on operation of Keyboard buttons.
<b>AnF</b>	:	Field Alarms
	<b>View</b>	= Visible if preset a Home page local HMI
	<b>Hidden</b>	= Presence not visible on Home page local HMI

## 4. Logic Blocking of Functions

### 4.1 - Blocking Outputs

The instantaneous element of each of the protection functions (1F50, 2F50, 3F50, 1F50N, 2F50N, 3F50N) can be programmed to control one of the Output Relays.

This relay picks-up as soon as the input quantity exceeds the set trip level of the Protection Function and it automatically resets when the input quantity drops below the function reset level ( $\approx 95\%$  of the trip level) or, in any case as soon as the time delay (tBF) of the Breaker Failure function is expired.

This instantaneous output can be used to activate the Blocking Input of another Protection Relay to implement a logic selectivity system. As above explained, in case of Breaker Failure, the blocking output is released, and the back-up protection enabled.

### 4.2 - Blocking Inputs

The time delayed tripping of any of the Protection functions (1F51, 2F51, 3F51, 1F51N, 2F51N, 3F51N) can be controlled by the activation of the Digital Input D1 (BI=Enable): in this case the set trip time delay of the function is increased by "2xtBF" so that other Protection Relays (set with the same trip time delay) that send the activation signal to the blocking Input D2, can trip before open and the C/B nearest to the Fault.

Also in this case, however, another "2xtBF" seconds from the expiry of the set trip time delay, the blocking input is disregarded so allowing the protection relay to trip in case of Failure to open of the upstream Circuit Breaker.

## 5. Output Relays

### 5.1 - Output Relay

0.R1	Programmable	<i>Available on the relay</i>
0.R2		
0.R3		
0.R4		

### 5.2 - "OutCfg" Outputs Configuration - via MCom2 software

#### 5.2.1 - "Example"

ID	Relay	Output config	Functions	OpLogic	Output config	Timer
1	0.R1 [Master board, R:1]	Normally Deenergized		None	Pulse	0

#### 5.2.2 - "Relay"

Relay internal name

#### 5.2.3 - "Output Configuration"

<i>Normally Deenergized</i>	The output relay is deenergized in normal conditions and gets energized on activation of the controlling Functional Output; reset means deenergizing.
<i>Normally Energized</i>	The output relay is energized in normal conditions and gets deenergized on activation of the controlling Functional Output; reset means energizing.

### 5.2.4 – "Function"

Select the function for tripping the output relay.

In this list are show the functions that can be associated with digital inputs or output relay.

<i>T&gt;</i>	<i>Ta</i> <i>T&gt;</i>	<i>Alarm</i> <i>Trip</i>	<i>Thermal Image T&gt;</i>
<i>I&gt;</i>	<i>I&gt;</i> <i>tI&gt;</i>	<i>Start</i> <i>Trip</i>	<i>First overcurrent element</i>
<i>I&gt;&gt;</i>	<i>I&gt;&gt;</i> <i>tI&gt;&gt;</i>	<i>Start</i> <i>Trip</i>	<i>Second overcurrent element</i>
<i>IH</i>	<i>IH</i> <i>tIH</i>	<i>Start</i> <i>Trip</i>	<i>Third overcurrent element</i>
<i>Io&gt;</i>	<i>Io&gt;</i> <i>tIo&gt;</i>	<i>Start</i> <i>Trip</i>	<i>First Earth Fault element</i>
<i>Io&gt;&gt;</i>	<i>Io&gt;&gt;</i> <i>tIo&gt;&gt;</i>	<i>Start</i> <i>Trip</i>	<i>Second Earth Fault element</i>
<i>IoH</i>	<i>IoH</i> <i>tIoH</i>	<i>Start</i> <i>Trip</i>	<i>Third Earth Fault element</i>
<i>BF</i>	<i>BF</i>	<i>Trip</i>	<i>Breaker Failure</i>
<i>IRF</i>	<i>IRF</i>	<i>Trip</i>	<i>Internal Relay Failure</i>
<i>CBopen</i>	<i>CBopen</i>	<i>Trip</i>	<i>C/B open command</i>
<i>CBclose</i>	<i>CBclose</i>	<i>Trip</i>	<i>C/B close command</i>
<i>HwRecov</i>	<i>HwRecov</i>	<i>Trip</i>	<i>Hardware Recovery</i>
<i>0.D1</i>	<i>Digital Input "0.D1"</i>	<i>activated</i>	<i>Digital Input on Main Module</i>
<i>0.D1NOT</i>	<i>Digital Input "0.D1"</i>	<i>deactivated</i>	
<i>0.D2</i>	<i>Digital Input "0.D2"</i>	<i>activated</i>	
<i>0.D2NOT</i>	<i>Digital Input "0.D2"</i>	<i>deactivated</i>	
<i>0.D3</i>	<i>Digital Input "0.D3"</i>	<i>activated</i>	
<i>0.D3NOT</i>	<i>Digital Input "0.D3"</i>	<i>deactivated</i>	


### 5.2.5 – "Operation Logic"

Operation Logic = [None, OR, AND]

### 5.2.6 – "Output Configuration"

Output Config = [Pulse, Automatic Reset, Manual Reset]

- Automatic** : In this mode the output relay is "operated" (energized if "**N.D.**", deenergized if "**N.E.**") when the controlling Functional Output is activated and it is reset to the "non operated" condition when the Functional Output gets deactivated but, anyhow, not before the time "**TIMER**" has elapsed (minimum duration of the operation time)
- Manual** : In this mode the output relay is "operated" when the controlling Functional Output is activated and remains in the operated condition until a manual reset command is issued by the relay keyboard (local commands menu) or via the serial communication. In this mode the timer "**TIMER**" has no effect.
- Impulsive** : In this mode the output relay is "operated" when the controlling Functional Output is activated and it remains in the "operated" condition (energized if "**N.D.**", deenergized if "**N.E.**") for the set time "**TIMER**" independently from the status of the controlling Functional Output.



### 5.2.7 – "Timer - Operation Time"

This timer controls the duration of the activation of the output relay.

Timer :  (0-10)s, step 0.01s


### 5.3 - Example: Change settings for "0.R1"

Change settings for "**0.R1**": "I>", "Normally Energized", "None", "Pulse", "0.5".


ID	Relay	Output config	Functions	OpLogic	Output config	Timer
1	0.R1 [Master board, R.1]	Normally Denergized		None	Pulse	0

#### 5.3.1 - "Output Config"

Select "**Output Config**" related to "0.R1" and press right button on mouse, select "Value change":




Select "**Normally Energized**" from combo box and press "OK" (if Password is request, see § Password)




#### 5.3.2 - "Functions"

Select "**Functions**" related to "0.R1" and press right button on mouse, select "Value change":




From box "Available", select "I>" and press "Add".  
Press "OK" for confirmation. (If Password is request, see § Password)




### 5.3.3 - "OpLogic"

Select "**OpLogic**" related to "0.R1" and press right button on mouse, select "Value change":




Select "**None**" from combo box and press "OK"  
(if Password is request, see § Password):




### 5.3.4 - "Output config"

Select "**Output config**" related to "0.R1" and press right button on mouse, select "Value change":




Select "**Pulse**" from combo box and press "OK"  
(if Password is request, see § Password):






### 5.3.5 - "Timer"

Select "**Timer**" related to "0.R1" and press right button on mouse, select "Value change":



Select "**0.5**" from combo box and press "OK" (if Password is request, see § Password):



The image shows two sequential screenshots of the "Value change" dialog box. Both windows have a title bar "Value change" and a light blue background. They are divided into two main sections: "Actual value" on the left and "Description" on the right. At the bottom of each window are "OK" and "Cancel" buttons.

**Top Screenshot:**

- Actual value:** A text box containing "0" with a small up/down arrow button to its right.
- Description:**
  - Name: R1Timer
  - Min: 0
  - Max: 10
  - Step: 0,01

**Bottom Screenshot:**

- Actual value:** A text box containing "0.5" with a small up/down arrow button to its right.
- Description:**
  - Name: R1Timer
  - Min: 0
  - Max: 10
  - Step: 0,01

## 6. Digital Inputs

The firmware can manage up to 3 digital inputs are available on the relay.

A Digital Input is activated when its terminals are shorted by a cold contact.

### 6.1 – Digital Input on Main Module (only via MSCom Software)

<b>D1</b>	(Terminals 22 - 19) :	It is usable as Function Blocking Input
<b>D2</b>	(Terminals 22 - 21) :	It is used for Remote Trip
<b>D3</b>	(Terminals 22 - 20) :	The digital Input indicates the position of the Circuit Breaker (Input Closed = C/B closed; Input Open = C/B open). If the option External Trigger = Enabled any time the DI passed from closed to open the oscillographic recording is started.

### 6.2 – Functions available

Select the function for tripping the output relay.

In this list are show the functions that can be associated with digital inputs.

Any of the Digital Inputs can be programmed to control one or more of the following functions.

<b>BiI&gt;</b>	Blocking input to the I>	<b>BiRCL</b>	Blocking input to the RCL
<b>BiI&gt;&gt;</b>	Blocking input to the I>>	<b>External Oscillo Trigger</b>	Oscillo external input trigger
<b>BiIH</b>	Blocking input to the IH	<b>CB</b>	CB status (52NA)
<b>BiIo&gt;</b>	Blocking input to the Io>		
<b>BiIo&gt;&gt;</b>	Blocking input to the Io>>		
<b>BiIoH</b>	Blocking input to the IoH		

## 7. Self-diagnostic

The relay incorporates a sophisticated self-diagnostic feature that continuously checks the following elements:

A/D conversion  
Checksum of the settings stored into E<sup>2</sup>Prom.  
DSP general operation (Power, Routines, etc.)  
Lamp test (only on manual test).


Any time Power is switched on, a complete test is run; then, during normal operation, the test runs continuously, and the checksum is done any time a parameter is stored into E<sup>2</sup>Prom.

If during the test any Relay Internal Failure (I.R.F) is detected:

If "I.R.F." is programmed to "Trip", the programmed output relays are operated same as on tripping of any protection function operation is stored in the "Event Records" and the I.R.F. signal led is set to flashing.  
If "I.R.F." is programmed to "NO Trip", and only the I.R.F. signal led is set to flashing.


## 8. Relay Management

The relay can be totally managed locally, either by the RS232 communication port or by the 4 key buttons and the LCD display, or remotely via the communication bus RS485 connected to the rear terminal blocks. The 2-line x 8 characters LCD display shows the available information. Key buttons operate according to the flow-chart herebelow.



## 9. Signalizations

Four signal leds are available on the Front Face Panel:



a)	<b>GREEN LED</b>	C/B OPEN	Illuminated when C/B open status is detected. (Digital Input D3 Open)
b)	<b>RED LED</b>	C/B CLOSED	Illuminated when C/B close status is detected. (Digital Input D3 closed) Flashing when Breaker Failure is detected.
c)	<b>RED LED</b>	TRIP (*)	Flashing when a timed function starts to operate. Illuminated when any function is tripped; reset takes places by pressing the reset button.
d)	<b>YELLOW LED</b>	PWR/ I.R.F.	Illuminated during normal operation when Power Supply is ON. Flashing when a Relay Internal Fault is detected.

(\*) When any protection function is tripped besides the Led which gives the general trip indication.  
The display shows the function that caused the tripping:

*LastTrip*                      steady  
*"Cause"*                      blinking

## 10. Keyboard Buttons



**Enter**      Give access to any menu or convalidate any programming chngement.



**Reset**      Return from the actual selected menu to the former menu.



**Select +**      Scrolls variables available in the different menus or increases/decreases setting values.



**Select -**

## 11. Serial Communication Port

### 11.1 - Main RS485 Serial Communication Port

This port is accessible via the terminals 1-2-3 provided on the relay terminal board.

It is used for connection to a serial bus interfacing up to 31 units with the Central Supervision System (SCADA, DCS, ecc).

The serial bus is a shielded pair of twisted cables connecting in parallel (Multi Drop) the different units (slaves) by the relevant terminals.

The physical link is RS485, and the Communication Protocol is MODBUS/RTU / IEC60870-5-103.

The configuration of transmission parameters is selectable.


<i>Baud Rate</i>	: 9600/19200 bps	9600/19200 bps	9600/19200 bps
<i>Start bit</i>	: 1	1	1
<i>Data bit</i>	: 8	8	8
<i>Parity</i>	: None	Odd	Even
<i>Stop bit</i>	: 1	1	1

**Note:** any change of this setting becomes valid at the next power on.

Each relay is identified by its programmable address code (NodeAd) and can be called from the P.C.

A dedicated communication software (MCom) for windows is available on [www.microelettrica.com](http://www.microelettrica.com).

Maximum length of the serial bus can be up to 200m.




For longer distance and for connection of up to 250 Relays, optical interconnection is recommended.  
(Please ask Microelettrica for accessories)

## 11.2 - Communication Port on Front Face Panel

This port is used for communication through the Front Face Panel between a local Lap-top PC.

The physical link is RS232 by the standard female 9-pin D-sub connector available on the Front Face Panel. Via this Port complete Relay management and data acquisition is possible.






## 12. Menu and Variables

### 12.1 - Real Time Measurements

Scrolling display of the Real Time Measurements is the Default operation.

Scrolling can be stopped at any of the measurements and restarted by pressing the Reset button .

When stopped on one variable,  appears aside the measurement and the different available measurements can be selected by the   buttons.

Display			Description
<b>I</b>	= 0 – 65535	%In	Largest of the 3 phase-currents (% of rated current)
<b>IA</b>	= 0 – 65535	A	RMS value of Phase A current
<b>IB</b>	= 0 – 65535	A	RMS value of Phase B current
<b>IC</b>	= 0 – 65535	A	RMS value of Phase C current
<b>Io</b>	= 0.0 – 6553.5	A	RMS value of Zero Sequence Current (RMS Primary Amps)
<b>Tem</b>	= 0 – 65535	%T	Actual temperature rise

### 12.2 - Measure (Instantaneous Measurements)


Real time measurements can be frozen at any moment selecting the menu "Instant Measure":



Display			Description
<b>I</b>	= 0 – 65535	%In	Largest of the 3 phase-currents (% of rated current)
<b>IA</b>	= 0 – 65535	A	RMS value of Phase A current (Primary Amps)
<b>IB</b>	= 0 – 65535	A	RMS value of Phase B current (Primary Amps)
<b>IC</b>	= 0 – 65535	A	RMS value of Phase C current (Primary Amps)
<b>Io</b>	= 0.0 – 6553.5	A	RMS value of Zero Sequence Current (Primary Amps)
<b>Tem</b>	= 0 – 65535	%T	Actual temperature rise

### 12.3 - Counter (Operation Counters)

The operation of any of the function herebelow reported, is counted and recorded in the menu "Counters".









Display			Description
<b>T&gt;</b>	= 0 – 65535		Number of Thermal Image
<b>I&gt;</b>	= 0 – 65535		Number of 1 <sup>st</sup> Overcurrent (time delayed) trip
<b>I&gt;&gt;</b>	= 0 – 65535		Number of 2 <sup>nd</sup> Overcurrent (time delayed) trip
<b>IH</b>	= 0 – 65535		Number of 3 <sup>rd</sup> Overcurrent (time delayed) trip
<b>Io&gt;</b>	= 0 – 65535		Number of 1 <sup>st</sup> time delayed Earth Fault trip
<b>Io&gt;&gt;</b>	= 0 – 65535		Number of 2 <sup>nd</sup> time delayed Earth Fault trip
<b>IoH</b>	= 0 – 65535		Number of 3 <sup>rd</sup> time delayed Earth Fault trip
<b>BF</b>	= 0 – 65535		Number of operations of Breaker Failure
<b>I.R.F.</b>	= 0 – 65535		Number of Internal Relay Faults
<b>HR</b>	= 0 – 65535		Number of HW recovery operations



## 12.4 - LastTrip (Event Recording)

The MC records any tripping and stores the information relevant to the last 20 tripping of protection functions (FIFO).

Each event recording includes the following information.




- "Real Time Meas" 
- "LastTrip" 
-  1<sup>st</sup> event,
-  to scroll available events,
-  to "Rec #" selected,
-  to select the different fields;

Display		Description
Rec. #x	xxxxx	Indication of the protection function which caused the relay tripping. For indication of the TRIP Cause the following acronyms are used: <i>T&gt;</i> = Thermal Image <i>I&gt;</i> = 1 <sup>st</sup> Overcurrent (Short Circuit) <i>I&gt;&gt;</i> = 2 <sup>nd</sup> Overcurrent (Short Circuit) <i>IH</i> = 3 <sup>rd</sup> Overcurrent (Short Circuit) <i>Io&gt;</i> = 1 <sup>st</sup> Earth Fault <i>Io&gt;&gt;</i> = 2 <sup>nd</sup> Earth Fault <i>IoH</i> = 3 <sup>rd</sup> Earth Fault <i>IRF</i> = Internal Relay Fault
Date	: YYYY/MM/GG	Date: Year/Month/Day
Time	: hh:mm:ss:ms	Time: hours/minutes/second/milliseconds
IA	= 0 – 65535 A	RMS value of phase A current (Primary Amps)
IB	= 0 – 65535 A	RMS value of phase B current (Primary Amps)
IC	= 0 – 65535 A	RMS value of phase C current (Primary Amps)
Io	= 0.0 – 6553.5 A	RMS value of Zero Sequence Current (Primary Amps)
Tem	= 0 - 65535 %T	Actual temperature rise

-  to go back to "Rec #",
-  to go back to "Real Time Meas".



## 12.5 - R/W Set (Programming / Reading the Relay Settings)

-  "Main Menu"  
 select "Function"  
 select among following sub menus:
















### 12.5.1 - CommAdd (Communication Address)

-  "CommAdd"  
 "Add: #"  
 "Password ????" (If not yet entered; see § Password)  
 to select the Address (1-250)  
 to validate. Set Done!








The default address is 1.

Display	Description	Setting Range	Step	Unit
Add: 1	Identification number for connection on serial communication bus	1 - 250	1	-

### 12.5.2 - Time/Date (Time/Date)










-  "Time/Date"  
 "YY/....."  
 "XX/MM"  
 "XX/XX/DD"  
 "XX/XX/XX"  
 "hh/mm"  
 "XX/mm"  
 To validate  
 Exit
-  Date: Current Date, Time: Current time  
 to set year,  
 to set month,  
 to set day,  
 to set hour,  
 to set minutes,  
 Set Done!

### 12.5.3 - RatedVal (Rated Input Values)

-  "RatedVal"  
 1<sup>st</sup> Variable  
 to scroll variables  
 to modify selected variable  
 "Password ????" (If not yet entered) or #???  
 (If not yet entered; see § Password)  
 to set variable value,  
 to validate. Set Done!

	Display	Description	Setting Range	Step	Unit
I1	100 A	Rated Primary current of phase C.T.	1 - 9999	1	A
I2	5 A	Rated Secondary current of phase C.T.	1 - 5	1/5	A
In	100 A	Reference primary current of the relay	1 - 9999	1	A
Freq	50 Hz	System rated frequency	50 - 60	10	Hz
TW	30 min	Warming-up time constant for Thermal Image	1 - 60	1	min.
Ib	105 %In	Maximum admissible continuous overload for Thermal Image	50 - 130	1	%In

### 12.5.4 - Function (Functions)





-  "Function",  
 1<sup>st</sup> function,  
 to scroll available Functions,  
 to Read/Write setting of the selected function,  
 to select the different definable fields  
- FuncEnab - TripLev  
- Options - Timers  
 to access the selected field and read the actual  
setting of the relevant variable  
 to modify the actual setting;  
 to set the new value.  
 to validate. Set Done!

Function	Type	Display Variable	Default Setting	Unit	Description	Setting Range	Step
<b>Password</b>		= 0000-9999	1111	-	Password for programming enable (see § Password)		
<b>T&gt;</b> (F49)	<i>FuncEnab</i>	→	Disable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→	NoParam		No Parameters	-	-
	<i>TripLev</i>	→ <i>Tal</i>	50	%Tb	Thermal prealarm	50 - 110	1
	<i>Timers</i>	→ <i>Tst</i>	100	%Tb	Reset level.	10 - 100	1
<b>I&gt;</b> (1F51)	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>TCC</i>	D		Time Current Curves	D, A, B, C, I, VI, EI, MI, SI	-
		→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
<b>I&gt;&gt;</b> (2F51)	<i>TripLev</i>	→ <i>I&gt;</i>	0.1	In	Trip level of overcurrent protection	0.1 - 4	0.01
	<i>Timers</i>	→ <i>tI&gt;</i>	0.05	s	Trip time delay	0.05 - 60	0.01
	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
<b>I&gt;&gt;&gt;</b> (3F51)		→ <i>2xI</i>	Disable		Automatic threshold doubling on inrush	Enable/Disable	-
		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
	<i>TripLev</i>	→ <i>I&gt;&gt;</i>	0.5	In	Trip level of overcurrent protection	0.5 - 40	0.01
	<i>Timers</i>	→ <i>tI&gt;&gt;</i>	0.05	s	Trip time delay	0.05 - 60	0.01
<b>I&gt;&gt;&gt;&gt;</b> (4F51)		→ <i>t2x I</i>	0.02	s	Trip time delay Automatic threshold doubling	0.02 - 9.99	0.01
	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
		→ <i>2xI</i>	Enable		Automatic threshold doubling on inrush	Enable/Disable	-
<b>I&gt;&gt;&gt;&gt;&gt;</b> (5F51)		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
	<i>TripLev</i>	→ <i>I&gt;&gt;&gt;</i>	0.5	In	Trip level of overcurrent protection	0.5 - 40	0.01
	<i>Timers</i>	→ <i>tI&gt;&gt;&gt;</i>	0.05	s	Trip time delay	0.05 - 60	0.01
		→ <i>t2xI</i>	0.02	s	Trip time delay Automatic threshold doubling	0.02 - 9.99	0.01
<b>Io&gt;</b> (1F51N)	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>TCC</i>	D		Time Current Curves	D, A, B, C, I, VI, EI, MI, SI	-
		→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
<b>Io&gt;&gt;</b> (2F51N)	<i>TripLev</i>	→ <i>Io&gt;</i>	0.01	Ion	Trip level of Earth Fault protection	0.01 - 4	0.01
	<i>Timers</i>	→ <i>tIo&gt;</i>	0.05	s	Trip time delay	0.05 - 60	0.01
	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
<b>Io&gt;&gt;&gt;</b> (3F51N)		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
	<i>TripLev</i>	→ <i>Io&gt;&gt;</i>	0.01	Ion	Trip level of Earth Fault protection	0.01 - 9.99	0.01
	<i>Timers</i>	→ <i>tIo&gt;&gt;</i>	0.05	s	Trip time delay	0.05 - 60	0.01
	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
<b>Io&gt;&gt;&gt;&gt;</b> (4F51N)	<i>Options</i>	→ <i>BI</i>	Disable		Operation controlled by Blocking Digital Input	Enable/Disable	-
		→ <i>Trg</i>	Enable		Function operation triggers the oscillographic wave form capture	Enable/Disable	-
	<i>TripLev</i>	→ <i>IoH</i>	0.01	Ion	Trip level of Earth Fault protection	0.01 - 9.99	0.01
	<i>Timers</i>	→ <i>tIoH</i>	0.05	s	Trip time delay	0.05 - 60	0.01
<b>BF</b> (F51BF)	<i>FuncEnab</i>	→	Enable		Enable of the protection function	Enable/Disable	-
	<i>Options</i>	→ <i>TrR</i>	Relay1		Output relay operated on BF tripping	Relay1- Relay2 Relay3- Relay4	-
	<i>TripLev</i>	→	No Parameters				
	<i>Timers</i>	→ <i>tBF</i>	0.2	s	Time delay for Breaker Failure alarm	0.05 - 0.75	0.01

Function	Type	Display Variable	Default Value	Unit	Description	Setting Range	Step
IRF	FuncEnab Options	→	No Parameters				
		→ Opz	NoTrip		Operation of output Relays on detection of Internal Relay Fault	NoTrip – Trip	-
	TripLev Timers	→	No Parameters				
		→	No Parameters				
Osc	FuncEnab Options	→	Enable		Enable of the protection function	Enable/Disable	-
		→ Trg	Trip		Trigger operation mode	Disable Start Trip Ext.Inp	-
	TripLev Timers	→	No Parameters				
		→ tPre	0.3		Recording time before Trigger	0.1 – 0.5	0.1
Comm	FuncEnab Options	→	No Parameters				
		→ LBd	9600		Local Baud Rate (Front panel RS232 communication speed)	9600 - 19200 38400	-
		→ RBd	9600		Remote Baud Rate (Rear panel terminal blocks RS485 communication speed)	9600 - 19200	-
		→ Mod	8,n,1		Remote mode (communication parameters)	8,n,1 8,o,1 8,e,1	-
	TripLev Timers	→	No Parameters		<b>Note: any change of this setting became valid at the next power on</b>		
		→ tPost	0.3		Remote Protocol	Iec103-Modbus	-
	FuncEnab Options	→	No Parameters				
		→ Key	BeepON		Buzzer "Beep" on operation of Keyboard buttons.	BeepON-BeepOFF	-
	TripLev Timers	→	No Parameters				
		→ BkL	Auto		LCD Backlight continuously "ON" or switched-on Automatically on operation of Keyboard buttons.	Auto - ON	-

Settings can also be programmed via the serial communication ports.








## 12.6 - Commands

-  "Commands"
-  1<sup>st</sup> Control,
-  to select other available control,
-  to operate selected control.

Display	Description
Clear	: Erase memory of Trip Counters, Event Records.
Test	: Starts a relay diagnostic test
Reset	: Reset after trip
CBopen	: Manual Open - Close Breaker
CBclose	: Manual Close - Close Breaker
ResThIm	: Reset Thermal Image

## 12.7 - Info&Ver (Firmware - Info&Version)

The menu displays the Relay Model and the Firmware Version

-  "Real Time Meas"
  -  "Info/Ver",
  -  "Model XXXXX",
  -  "RelayVrs ###.##.##X",
  -  to go back to "Info&Ver".
  -  to go back to "Real Time Meas"
-  Model Relay  
Firmware Version















## 14. Password

This password is requested anytime the user wants to write in the "Settings" menu a command of the "Commands" menu.


The default password is "1111"

When password is required, proceed as follows

The Display shows the message "Password ????"

		to select 1 <sup>st</sup> digit (1-9)		to validate
		to select 2 <sup>nd</sup> digit (1-9)		to validate
		to select 3 <sup>rd</sup> digit (1-9)		to validate
		to select 4 <sup>th</sup> digit (1-9)		to complete procedure.

The "password" is required any time you attempt to modify one of the programmable variables at the first entrance in the "Settings" and/or "Commands" menus.

The "password" remains valid for 2 minutes from the last operation of the programming buttons or until the  button is pressed to return to the default display (RT Meas).

Once the Password has been entered, a "#" appears before the variable that can be modified.

### 14.1 - MS-Com Password

This password is requested anytime the user wants to send to the relay a setting parameters modification or to issue a command through the relay itself using the managing software MCom.

The user can decide whether inserting his own password (see MS-Com Operational Manual) or keeping the password disabled just clicking on the OK button when the password is requested.


## 15. Maintenance

No maintenance is required. In case of malfunctioning please contact Microelettrica Scientifica Service or the local Authorised Dealer mentioning the relay's Serial No reported in the label on relays enclosure.

## 16. Power Frequency Insulation Test


Every relay individually undergoes a factory insulation test according to IEC255-5 standard at 2 kV, 50 Hz 1min. Insulation test should not be repeated as it unusefully stresses the dielectrics. When doing the insulation test, the terminals relevant to serial output, digital inputs and RTD input must always be short circuited to ground. When relays are mounted in switchboards or relay boards that have to undergo the insulation tests, the relay should be isolated. This is extremely important as discharges eventually tacking place in other parts or components of the board can severely damage the relays or cause damages not immediately evident to the electronic components.

## 17. Connection Diagram



## 18. Overall Dimensions

Protection Degree IP44 (On Request IP54)




## 19. Direction for Pcb's Draw-Out and Plug-In

### 19.1 - Draw-Out

Rotate clockwise the screws ① in the horizontal position of the screws-driver mark.  
Draw-out the PCB by pulling on the handle ②

### 19.2 - Plug-In

Rotate clockwise the screws ① in the horizontal position of the screws-driver mark.  
Slide-in the card on the rails provided inside the enclosure.  
Plug-in the card completely and by pressing the handle to the closed position.  
Rotate anticlockwise the screws ① with the mark in the vertical position (locked).



## 20. Electrical Characteristics

### APPROVAL: CE

### REFERENCE STANDARDS IEC 60255 - CE Directive - EN/IEC61000 - IEEE C37

Dielectric test voltage	IEC 60255-5	2kV, 50/60Hz, 1 min.
Impulse test voltage	IEC 60255-5	5kV (c.m.), 2kV (d.m.) – 1,2/50µs
Insulation resistance	> 100MΩ	

### Environmental Std. Ref. (IEC 60068)

Operation ambient temperature	-10°C / +55°C
Storage temperature	-25°C / +70°C
Environmental testing	(Cold) IEC60068-2-1
	(Dry heat) IEC60068-2-2
	(Change of temperature) IEC60068-2-14
	(Damp heat, steady state) IEC60068-2-78 RH 93% Without Condensing AT 40°C

### CE EMC Compatibility (EN61000-6-2 - EN61000-6-4 - EN50263)

Electromagnetic emission	EN55011/22	industrial environment
Radiated electromagnetic field immunity test	IEC61000-4-3	level 3 80-2000MHz 10V/m
	ENV50204	900MHz/200Hz 10V/m
Conducted disturbances immunity test	IEC61000-4-6	level 3 0.15-80MHz 10V
Electrostatic discharge test	IEC61000-4-2	level 3 6kV contact / 8kV air
Power frequency magnetic test	IEC61000-4-8	1000A/m 50/60Hz
Pulse magnetic field	IEC61000-4-9	1000A/m, 8/20µs
Damped oscillatory magnetic field	IEC61000-4-10	100A/m, 0.1-1MHz
Immunity to conducted common mode disturbance 0Hz-150KHz	IEC61000-4-16	level 4
Electrical fast transient/burst	IEC61000-4-4	level 3 2kV, 5kHz
HF disturbance test with damped oscillatory wave (1MHz burst test)	IEC60255-22-1	class 3 400pps, 2,5kV (m.c.), 1kV (d.m.)
Oscillatory waves (Ring waves)	IEC61000-4-12	level 4 4kV(c.m.), 2kV(d.m.)
Surge immunity test	IEC61000-4-5	level 4 2kV(c.m.), 1kV(d.m.)
Voltage interruptions	IEC60255-4-11	
Resistance to vibration and shocks	IEC60255-21-1 - IEC60255-21-2	10-500Hz - 1g

### Electric Rated Value

Accuracy at reference value of influencing factors (*)	2% In (*)	for measure
$\frac{I_n}{I_{on}} = \text{Nominal Current of the System's Current Transformer}$	0,2% On (*)	
	2% + to (to=20÷30ms @ 2xIs)	for times
Rated Current	In = 1A/5A - On = 1A/5A	
Current overload	400 A for 1 sec; 20A continuous	
Burden on current inputs	Fase : 0.1VA a In = 1A ; 0.3VA a In = 5A	
Average power supply consumption	≤ 7 VA	
Output relays	rating 6 A; Vn = 250 V	
	A.C. resistive switching = 1500VA (400V max)	
	make = 30 A (peak) 0,5 sec.	
	break = 0.3 A, 110 Vcc,	
	L/R = 40 ms (100.000 op.)	

### Communication Parameters

RS485 (Back)	9600/19200 bps – 8,n,1 - 8,e,1 - 8,o,1 – Modbus RTU or IEC60870-5-103
RS232 (Front)	9600/19200/38400/57600 – 8,n,1 – Modbus RTU

This publication may be subject to alteration without prior notice. Therefore, a printed copy of this document may not be the latest revision. Please contact your local representative for the latest update. The trademarks MS Microelettrica Scientifica, Knorr and Knorr-Bremse as well as the figurative mark "K" are registered. Copyright © Knorr-Bremse AG and Microelettrica Scientifica SpA - all rights reserved, including industrial property rights application. Knorr-Bremse AG and Microelettrica Scientifica SpA retain any power of disposal, such as for copying and transferring.



20090 Buccinasco (MI) · Via Lucania 2 · Italy · Tel.: +39 02 575731  
E-Mail: info@microelettrica.com · www.microelettrica.com